


8312 Tank Gate Interface

The 8312 scans up to 16 slave devices on a single channel via SAAB TRL/2 fieldbus Communications

DVR Firmware Version: SBTG1_11



Varec[®]

Copyright

All rights reserved. Printed in the United States of America.

Except as permitted under the United States Copyright Act of 1976, no part of this publication may be reproduced, stored in a retrieval system or transmitted in any form or by any means – electronic, mechanical, photocopying, recording, or otherwise – without the prior written permission of the Publisher:

Varec, Inc.
5834 Peachtree Corners East
Norcross (Atlanta), Georgia 30092
Phone: (770) 447-9202
Fax: (770) 662-8939

Trademarks Acknowledged

Varec, Inc. recognizes all other trademarks. Trademarks of other products mentioned in this manual are held by the companies producing them.

FuelsManager® and Varec® are registered trademarks of Varec, Inc.

Acrobat Reader® is a registered trademark of Adobe Systems Incorporated.

MODBUS® is a registered trademark of Modicon, Inc.

All other product and service names mentioned are the trademarks of their respective companies.

Disclaimer of Warranties

The contract between the Seller and the Buyer states the entire obligation of the Seller. The contents of this instruction manual shall not become part of or modify any prior or existing agreement, commitment, or relationship between the Seller and Buyer. There are no express or implied warranties set out in this instruction manual. The only warranties that apply are those in the existing contract between the Seller and Buyer.

The 8300 TGI has not been tested by Varec under all possible operational conditions, and Varec may not have all the data relative to your application. The information in this instruction manual is not all inclusive and does not and cannot take into account all unique situations. Consequently, the user should review this product literature in view of his or her application. If you have any further questions, please contact Varec for assistance.

Limitations of Seller's Liability

In the event that a court holds that this instruction manual created some new warranties, Seller's liability shall be limited to repair or replacement under the standard warranty clause. In no case shall the Seller's liability exceed that stated as Limitations of Remedy in the contract between the Seller and Buyer.

Use of parts that are not manufactured or supplied by Varec voids any warranty and relieves Varec of any obligation to service the product under warranty. Varec recommends the use of only Varec manufactured or supplied parts to maintain or service the 8300 TGI.

Terms of Use

The information provided in this document is provided "as is" without warranty of any kind. Varec, Inc. disclaim all warranties, either express or implied, including the warranties of merchantability and fitness for a particular purpose. In no event shall Varec, Inc. or its suppliers be liable for any damages whatsoever including direct, indirect, incidental, consequential, loss of business profits or special damages, even if Varec, Inc. or its suppliers have been advised of the possibility of such damages.

This manual is solely intended to describe product installation and functions and should not be used for any other purpose. It is subject to change without prior notice. This manual was prepared with the highest degree of care. However, should you find any errors or have any questions, contact one of our service offices or your local sales agent.

Safety Precaution Definitions

Caution! Damage to equipment may result if this precaution is disregarded.

Warning! Direct injury to personnel or damage to equipment which can cause injury to personnel may result if this precaution is not followed.

Safety Precautions

Read this manual carefully and make sure you understand its contents before using this product. Follow all instructions and safety guidelines presented in this manual when using this product. If the user does not follow these instructions properly, Varec cannot guarantee the safety of the system.

Note Comply with all applicable regulations, codes, and standards. For safety precautions, the user should refer to the appropriate industry or military standards.

Caution! Electrical Hazard! Read and understand static and lightning electrical protection and grounding described in API 2003. Make certain that the installation, operation, and maintenance conforms with the practice set forth therein.

Warning! Striking the product with a metal object could cause a spark to occur. When removing or replacing the product in flammable or hazardous liquid storage areas, take necessary measures to protect it from impact.

Warning! Sparks or static charge could cause fire or explosion! Mechanical connections, worker activity and worker clothing may accumulate electrostatic charges. Care should be used in flammable environments to avoid the hazard.

Contents

1	Overview	1
1.1	Versions	1
1.2	Features	1
1.3	Applications	2
1.4	Specifications	2
1.4.1	System Design	2
1.4.2	Software Functionality	2
1.4.3	Host Communication	2
1.4.4	Modbus Functionality	2
1.4.5	Power Supply	2
1.4.6	Power consumption	2
1.4.7	Surge protection	3
1.4.8	Operating temperature	3
1.4.9	Humidity	3
1.4.10	Storage temperature	3
1.4.11	Mechanical Construction	3
2	Hardware	5
2.1	Hardware Block Diagram	5
2.2	Motherboard Description	5
2.2.1	Power Supply	7
2.2.2	Switches and Indicators	9
2.2.3	Communications	10
3	8212 SAAB TRL/2 Communications Interface Module	15
3.1	Features	15
3.2	Description	15
3.2.1	ID DIP Switch (SW1)	17
3.2.2	LED Indicators (D1 -D4)	17
3.2.3	Surge/Shield Ground Connector (J2)	17
3.2.4	Field Wiring terminal block (J1)	17
3.2.5	Center Frequency Adjustment Pot (R22)	18
3.2.6	Capture Frequency Bandwidth Adjustment Pot (R23)	18
4	Software Description	19
4.1	Software Features	19
4.1.1	Real-Time / Multitasking Executive	19
4.1.2	Real-Time Clock	19
4.1.3	Automatic Fault Recovery	19
4.1.4	Communications	20

4.1.5 Protocols	20
4.1.6 Data Scanning Task.	20
4.1.7 Database Manager	20
4.1.8 System Tasks	21
4.1.9 Tank Gate Interface Software Blocks	21
4.2 Database Organization	21
4.2.1 Point Format	21
4.2.2 Parameter Description	21
4.3 Gathering Point Data	23
4.3.1 Standard Request-Response Format	23
4.3.2 Change of State Format	23
4.3.3 Change of State-Related Parameters.	24
4.3.4 Modbus Communications	24
4.3.5 Fixed Modbus Map	26
4.3.6 GWBLK method	26
4.4 Common Software Blocks.	29
4.4.1 Clock (CLK)	29
4.4.2 Communications (COM)	29
4.4.3 Floating Point Register (FPREG).	31
4.4.4 Emulator (EMU).	31
4.4.5 EMU Gateway (EMUGW)	33
4.4.6 Gateway Block (GWBLK)	34
4.4.7 Integer Register (IREG)	36
4.4.8 Modbus Gateway (MODGW)	36
4.4.9 Scaler Point (SCALER)	38
4.4.10 System Information (SYS).	39
5 SAAB TRL/2 Software Blocks	41
5.1 Saab Data Acquisition Unit (DAU)	43
5.1.1 Parameters	43
5.1.2 Application	46
5.2 Modbus Floating Point Register (MFPREG)	49
5.2.1 Parameters	49
5.2.2 Application	50
5.3 Modbus Scanner (MSCAN)	51
5.3.1 Parameters	51
5.3.2 Application	52
5.4 Rosemount RAPTOR RTG (RAPTOR).	55
5.4.1 Parameters	55
5.5 SAAB REX Radar (REX)	59
5.5.1 Parameters	59
5.5.2 Application	63
5.6 Saab Radar Tank Gauge (RTG)	65

5.6.1 Parameters	65
5.6.2 Application	67
6 Installation	69
6.1 General Safety Guidelines	69
6.2 Installation Safety Guidelines	69
6.3 Installation	70
6.3.1 Mounting the Tank Gate Interface	70
6.3.2 Select the Unit Address	70
6.3.3 Wiring Up Power	70
6.3.4 Grounding	72
6.3.5 Installing Communications	72
7 Using ViewRTU	73
7.1 Overview	73
7.2 System Requirements	73
7.3 Installing ViewRTU	73
7.4 Executing ViewRTU	73
7.4.1 ViewRTU window	75
7.5 The ViewRTU Menu Bar	75
7.5.1 The File Menu	75
7.5.2 The Point Menu	76
7.5.3 The Config Menu	79
7.5.4 The Communications Menu	81
7.5.5 The Options Menu	83
7.5.6 The Help Menu	84
7.6 Using ViewRTU	85
7.6.1 Overview	85
7.6.2 Configuring Single Points	86
7.6.3 To modify a Value	88
7.6.4 Configuring Multiple Points	90
7.6.5 Creating and Editing Connections	96
8 Troubleshooting	99
8.1 Overview	99
8.2 Troubleshooting the Tank Gate Interface	99
8.2.1 LED Displays under normal conditions	99
8.2.2 LED Displays under Abnormal Conditions	100
8.2.3 Using the Tank Gate Interface Push-buttons	100
8.2.4 Performing a Hard Reset	101
8.3 Maintenance	102

A Appendix - Order Codes 105

1 Overview

The 8300 series Tank Gate Interface acts as a tank gauge interface for data acquisition and host gateway for tank farm, pipeline or refinery applications. Options are available for interfacing to nearly any brand of tank gauge equipment or technologies, making it possible to integrate float and tape transmitters, HTG, servo, magnetostrictive and radar gauges.

Each 8300 series Tank Gate Interface unit has a built-in motherboard and specific communications module based on the local field protocol or tank gauging instrumentation requirements. The motherboard contains a serial data link to enable communication to a host PC, PLC, or DCS.

Note! Each intelligent module is identified by a 82xx designation that matches the product designation, for example, the 8303 TGI contains a 8203 communications module.

Each module contains its own processor for fast and reliable field data scanning. Compatibility of every module also makes configuration of the internal database simple and straightforward.

1.1 Versions

The 8300 series Tank Gate Interface is available in a number of versions that can interface to a variety of field devices and intelligent instrumentation via interface modules listed below:

- 8303-2 Dual RS-485 (MODBUS) Communications Tank Gate Interface
- 8303-6 Dual RS-485 (GSI ASCII) Communications Interface Module
- 8310 Varec Mark/Space (Varec 1800, 1900, 4000) Tank Gate Interface
- 8311-1 Current Loop (Whessoe Bus) Tank Gate Interface
- 8311-2 Current Loop (GPE) Tank Gate Interface
- 8312 Saab (TRL/2) Tank Gate Interface
- 8314 Enraf (811, 802/812, 854, 873) Tank Gate Interface
- 8315 L&J Tankway (MCG 1000, MCG 1500, MCG 2000) Tank Gate Interface
- 8316 LON (Prime Measurement 3500 ATG) Tank Gate Interface
- 8317 Dual RS-232 Veeder Root (TLS 350) Tank Gate Interface

1.2 Features

- Inputs are reported to Host Computer by Exception or Scanned Poll
- Built-in Software Function Library
- Surge Protection Conforming to ANSI/IEEE C37.90a-1974
- Host Communication via RS-232, RS-485, radio, modem or fiber optic link
- Industry Standard Protocol: Modbus
- Quick-Disconnect I/O Terminations
- Modular Construction for Optimum Expandability
- Non-Volatile Database

1.3 Applications

The 8300 series Tank Gate Interface is ideally suited for Tank Farm, Terminal, Pipeline and Refinery applications. It is an effective solution used in SCADA applications.

- Level, temperature, pressure, flow, local indication, and alarms
-

1.4 Specifications

1.4.1 System Design

- 16-bit processor with optional intelligent communication modules
- Intelligent field device communications
- 128K bytes Non-Volatile Database Memory
- Serial RS-232
- Visual indication – 4 LEDs on main board indicate power and status

1.4.2 Software Functionality

- Tank gauge scanning – Data acquisition of measured values from connected tank gauges/transmitters
- Service & diagnostics*
- Gauge diagnostics
- Read level, temperature and status data from gauge/transmitter

1.4.3 Host Communication

- Host comm. ports – 2
- Comm. type:
 - COM 0: RS-232C
 - COM 1: RS-232C or RS485
- Baud Rate – selectable baud rate depending on equipment parameters
- Protocol – Modbus™ RTU protocol
- Mode – RTU mode, master and slave
- Media access – Master/Slave

1.4.4 Modbus Functionality

- Modbus™ commands – 3, 4, 5, 6, 15, 16
- Modbus™ mapping – Configurable

1.4.5 Power Supply

- Supply 100...240 Vac, 50/60 Hz

1.4.6 Power consumption

- 50 VA max (500 mA)

1.4.7 Surge protection

- Gas Discharge Tubes (GDTs) and clamping diodes on all field inputs, power supply inputs and communications channels

1.4.8 Operating temperature

- -40...+185 °F (-40...+85 °C)

1.4.9 Humidity

- 5...95% (non-condensing)

1.4.10 Storage temperature

- -40...+212 °F (-40...100 °C)

1.4.11 Mechanical Construction

- Dimensions (HxDxW) – 2.5" (64 mm) x 8.6" (220 mm) x 5.2" (133 mm)
- Material – Aluminum Powder coated

*Gauge/transmitter Dependent

2 Hardware

The Tank Gate Interface consists of an enclosure, motherboard, single tank gauge interface module and connectors.

2.1 Hardware Block Diagram

A Tank Gate Interface hardware functional block diagram is shown below. This diagram shows the relationship between major subsystems and components in the Tank Gate Interface.

The heart of the Tank Gate Interface is an Intel 80C188EB microprocessor operating at 18.432 MHz. Designed specifically for real-time embedded applications, the μ P includes timer/counters, an interrupt controller, and chip-select circuitry. It also includes 2 serial channels that are designated as COM0 and COM1.

2.2 Motherboard Description

The motherboard description is broken into three sections. Each section identifies the location of the components on the motherboard. When necessary, a brief description of the component is provided. These sections are listed below:

- Power Supply
- Switches and Indicators
- Communications




Figure 2-1: Tank Gate Interface Hardware Components




Figure 2-2: The Tank Gate Interface Motherboard




Figure 2-3: Tank Gate Interface Functional Block Diagram

2.2.1 Power Supply

- Unit AC Power terminal block (J2)
- Surge Protection terminal block (J4)
- Field Power terminal block (J3)
- Auxiliary DC Power Output terminal block (J8)
- AC Power fuses (500 mA – 250V 5x20 mm) (F1, F2)
- Field Voltage Selection Jumper (W3)

2.2.1.1 Unit AC Input Power terminal block (J2)

The Unit AC power terminal block is used to provide AC power to the Tank Gate Interface. The power requirements for the Tank Gate Interface are 100–240 VAC, 50/60 Hz. The AC Input Power terminal block is shown in the figure below.




Figure 2-4: AC Input Terminal Block

2.2.1.2 Surge Protection (Surge Gnd) terminal block (J4)

The Surge Gnd terminal block is used to connect the surge protection components (gas tubes, MOVs) to earth ground. Ensure there is a low impedance path ($< 1\text{ ohm}$) to earth ground (a ground rod or grounding system).

2.2.1.3 Field Power (VFIELD) terminal block (J3)

The Field Power terminal block, referred to as VFIELD, is used to provide power for field instruments. The output is configurable using jumpers (Jumper W3, discussed below).




Figure 2-5: Field Power Terminal Block

2.2.1.4 Auxiliary DC Output Power terminal block (J8)

The Auxiliary power terminal block is used when external equipment must be powered from the Tank Gate Interface's internal power supply. The triple output power supply provides +5, +15 and -15 Volts. These are rated 210 mA, 50 mA, and 5 mA, respectively. The DC Power terminal block is shown below.

T




Figure 2-6: DC Input Voltage Terminal Block

2.2.1.5 AC Power Fuses (F1,F2)

The AC Power Fuses provide protection for the AC input power. The two fuses, F1 and F2, are rated at 500 mA, 250 V.




Figure 2-7: AC Power Fuse

2.2.1.6 Field Voltage Selection Jumper (W3)

The Field Voltage Selection Jumper W3 determines the voltage available at the VFIELD terminals (J3). The Field Voltage can be configured for +24 VDC or +48VDC. At +24VDC, there is 230 mA of field power available. At +48VDC, there is 230 mA of field power available.




Figure 2-8: Selection Jumper W3

2.2.2 Switches and Indicators

2.2.2.1 Reset push-button (SW3)

The RESET Switch is used to re-initialize the system hardware by causing it to go to a known starting state. This switch may be pressed at any time; however, it will do the following:

- Re initialize System Hardware
- Clear Scratch Memory
- Verify Database and Re initialize if Invalid
- Reset All Timers
- Enable Communications




Figure 2-9: Switches SW3 on the Tank Gate Interface Motherboard

2.2.2.2 Hard Reset

A special form of Reset is available for occasions when the battery backed-up data base must be re-initialized. This type of reset, the Hard Reset, can be performed before a database is downloaded from a host PC.

Caution! The Hard Reset should be used as a last resort if the Tank Gate Interface is not functioning. A Hard reset clears the installed database. For the Hard Reset procedure, refer to the Troubleshooting and Maintenance chapter.

2.2.3 Communications

The Communications installation requires connection of the appropriate communication cable to one of two connectors. The available options include RS-232 and RS-485 communications.

- COM0 (RS-232) (J7)
- COM1 (RS-232 or RS-485) (J5)
- COM1 Transmit Control (RS-232) (J6)
- COM1 Hardware Handshaking Switch (SW1)
- COM1 RS-232/RS-485 Selection Switch (SW2)
- COM1 RS-485 Terminating Resistor Jumper (W2)

Note COM1 is not available on the 8315 Tank Gate Interface




Figure 2-10: COM1 J5 Terminal Block

2.2.3.1 COM0 (J7)

COM0 is an RS-232 port for use in diagnostic testing/local programming or communications to a host system. The protocol defaults to Tank Gate Interface Slave at the 9600 baud, 8 data bits, and no parity (for use with ViewRTU or FuelsManager).




Figure 2-11: COM0 J7 Terminal Block

2.2.3.2 COM1 (RS-232/RS-485) (J5)

Note COM1 is not available on the 8315 Tank Gate Interface

RS-232 is one of the two types of high-speed serial communications channels available to interface to Host systems using several different protocols. RS-232 will operate at distances up to 100 feet, while RS-485 allows multidrop communications at distances up to 4000 feet. RS-232 can be used for flexibility in configuring other types of communications links. Other variations of RS-232 communications interfaces include radio, modem and fiber optic interfaces.

The choice of RS-232 or RS-485 is determined by the COM RS-232/RS-485 Selection Switch SW2.

2.2.3.3 COM1 RS232/RS-485 Selection Switch (SW2)

Note COM1 is not available on the 8315 Tank Gate Interface

Switch SW2 determines whether RS-232 or RS485 is used. Note that the Hardware Handshaking Switch SW1 affects the operation of COM1.




Figure 2-12: COM1 SW2 Switch

2.2.3.4 COM1 Hardware Handshaking Switch (SW1)

Note COM1 is not available on the 8315 Tank Gate Interface

For RS-232, there are two different settings. One setting is used if hardware handshaking (RTS/CTS) is required. The other setting eliminates the need for hardware handshaking. Set the Hardware Handshaking Switch to the 'A' position to use RTS/CTS when a modem or signal converter is involved and requires RTS/CTS to operate. The RTS and CTS signals will be available on terminal block J6. If the connection is direct using RS-232, jumper RTS to CTS by setting SW1 to the 'B' position.




Figure 2-13: COM1 SW1 Switch

For RS-485, set the Hardware Handshaking Switch SW1 to the 'A' position. Refer to the following table:.

Comm. Physical Layer	Hardware Handshake	SW1 Setting	SW2 Setting	Notes
RS-232	No	A	UP (towards the RS-232 side)	Use with a PC. Signals at terminal block J5 will be RS-232
RS-232	Yes	B	UP (towards the RS-232 side)	Use to communicate to systems that require Request To Send (RTS) in order to transmit (Modems, Radios, etc.) RTS and CTS signals will be available at terminal block J6
RS-485	Yes	A	DOWN (towards the RS-485 side)	Always SW1 set to the A position when using RS-485..

Table 2-1: Tank Gate Interface Communications Cable

The layout for the RS-232 cable between the PC and the Tank Gate Interface is shown in the following illustrations.




Figure 2-14: COM1 Cable without RTS/CTS

Note COM1 is not available on the 8315 Tank Gate Interface.

3 8212 SAAB TRL/2 Communications Interface Module

This communications interface module is the processing card that mounts on the Tank Gate Interface (TGI) motherboard. The firmware installed on this card determines which protocol is provided.

Firmware Version	Protocol	Software Blocks
SBTG1_11	SAAB TRL/2	See section 5 on page 41

3.1 Features

- Saab TRL/2 Bus
- Up to 16 Saab Radar Tank Gauges per channel
- Two channels
- Fully isolated

Note The 8312 Tank Gate Interface uses the 8212 communications module.

The 8212 communications module is designed to communicate with Saab Radar Tank Gauges directly over the TRL/2 Bus. The TRL/2 Bus uses a Frequency Shift Keying signaling method. The RTG software point converts level and temperature data into the IEEE floating point format.

3.2 Description

The components of the 8212 communications module are illustrated in the following figure. This section explains how to connect field wiring and how to configure jumper settings.

- ID DIP Switch (SW1)
- LED Indicators (D1 – D4)
- Surge/Shield ground connector (J2)
- Field Wiring terminal block (J1)
- Center Frequency Adjustment Pot (R22)
- Capture Frequency Bandwidth Adjustment Pot (R23)




Figure 3-1: SAAB TRL/2 Tank Gate Interface Module

3.2.1 ID DIP Switch (SW1)

The dip switch is used for setting the ID number (1–14). The ID is a binary number representing the address of the 8317 TGI.

Table 3-1: ID DIP Switch settings


<div><div>CLOSED</div><div>OPEN</div><div><div>1234</div><div><div></div><div></div><div></div><div></div></div></div></div> <div>Address 1 Shown</div>										
Binary	8	4	2	1		Binary	8	4	2	1
Switch #	1	2	3	4		Switch #	1	2	3	4
Address 1	o	o	o	c		Address 8	c	o	o	o
Address 2	o	o	c	o		Address 9	c	o	o	c
Address 3	o	o	c	c		Address 10	c	o	c	o
Address 4	o	c	o	o		Address 11	c	o	c	c
Address 5	o	c	o	c		Address 12	c	c	o	o
Address 6	o	c	c	o		Address 13	c	c	o	c
Address 7	o	c	c	c		Address 14	c	c	c	o

3.2.2 LED Indicators (D1 -D4)

The LED displays indicate the status of the Model 8212’s CPU and communications.

- CPU: CPU activity
- COM: Communication between the 8130 RTU and the Model 8212
- TXD: Model 8212 is transmitting to gauge
- RXD: Valid message received from gauge

Figure 3-2: LED indicators



3.2.3 Surge/Shield Ground Connector (J2)

Caution! This ground connection is important for system safety.

- Connect a 14 AWG copper wire between the ground terminal (J2) and a good earth ground. Perform this step before connecting ANY other wires.
- Verify that the resistance in this connection does not exceed 1 ohm.

3.2.4 Field Wiring terminal block (J1)

A schematic illustrating the terminal connections of the Model 8212 is shown below:




Figure 3-3: Terminal connections

3.2.4.1 Connect the field wiring

Connect the wiring according to the following diagram.




Figure 3-4: Multiple Gauge Connection

3.2.5 Center Frequency Adjustment Pot (R22)

The Center Frequency Adjustment pot is preset at the factory. Do not adjust R22.

3.2.6 Capture Frequency Bandwidth Adjustment Pot (R23)

The Capture Frequency Bandwidth Adjustment pot is preset at the factory. Do not adjust R23.

4 Software Description

The Tank Gate Interface software platform is based on a real-time, multi-tasking operating system. The software consists of I/O scanning functions for data acquisition, a database/database manager and communication functions for data transfer.

Note COM1 is not available on the 8315 Tank Gate Interface.




Figure 4-1: Software Block Diagram

4.1 Software Features

4.1.1 Real-Time / Multitasking Executive

The operation of the Tank Gate Interface is based on a highly reliable, field-proven real-time multitasking executive. It provides task switching based on real-time events and interrupts, message passing and task priorities. Its capabilities also include timed suspension of tasks, queue handlers and interrupt processing tasks.

4.1.2 Real-Time Clock

Integral to the real-time executive is the system's real-time clock. All timed events of the Tank Gate Interface are coordinated by this clock. In addition to the real-time executive interaction, all field data scanning is coordinated by the real-time clock.

4.1.3 Automatic Fault Recovery

The Tank Gate Interface has a watchdog timer that is periodically strobed by the microprocessor. Should the processor suffer a lapse due to hardware or software failure, the watchdog timer will time out and the Tank Gate Interface will then be reset and normal operation will resume.

4.1.4 Communications

There are two communications tasks – one for each of the communication channels. COM ports 0 and 1 are used to interface to external devices or host systems. Refer to the Hardware Chapter for the location of these ports.

Note COM1 is not available on the 8315 Tank Gate Interface.

COM0 and COM1

COM 0 and 1 can be configured for communications to Host systems using a variety of protocols. For COM 0 and 1 the communication interfaces include the following:

- RS-485 for use in multi-drop configurations or long cable runs (or both)
- RS-232 for flexibility in configuring other types of communications links such as radio and fiber optic interfaces
- RTS/CTS lines are available for hardware handshaking.

4.1.5 Protocols

The Tank Gate Interface is fully compatible with FuelsManager® software. It is also compatible with a variety of other Host systems including through Modbus protocol.

- RS-485 for use in multi-drop configurations or long cable runs (or both), with an RS232-to-RS485 converter.
- RS-232 for flexibility in configuring other types of communications links such as radio and fiber optic interfaces.

The default communication settings for the COM ports are as follows:

COM Port	Protocol	Baud Rate	Data Bits	Parity	Stop Bits
COM0	RTU Slave or Modbus – Auto-sensing	9600	8	N	0
COM1	Modbus	9600	8	N	0

Note COM1 is not available on the 8315 Tank Gate Interface.

4.1.6 Data Scanning Task

The Data Scanning Task is dedicated to the scanning of field input data from tank gauges. The input data is stored in arrays that are subsequently accessed by the Point Executive.

4.1.7 Database Manager

The Database Manager is a collection of programs and data. The Database Manager allows the Tank Gate Interface system executive to access data from the database in an organized and program-independent manner. It resides in non-volatile RAM.

The Database Manager also contains a Database Dictionary. This dictionary describes how the database is organized and also provides information describing how data should be presented to the operator.

After power-up or system reset, a CRC verification of each point in the database is performed. If the CRC does not have a match for the point, then it is disabled and a flag is set indicating that the point is invalid.

4.1.8 System Tasks

System tasks include the Calendar Task, which manages Time and Date functions. Other system tasks include utility routines for checksum calculations, diagnostics, start-up and initialization.

4.1.9 Tank Gate Interface Software Blocks

The user can configure pre-defined subprograms known as Software Blocks. These software blocks program the Tank Gate Interface to perform various tasks, such as scaling an analog input value, or scanning level, temperature and status information from a tank gauge. Various software blocks are available depending on the communication module. Each Software Block contains all the logic, constants and data to perform a particular function. Every system function of the Tank Gate Interface is accessible via a Software Block. The user only has to add Software Blocks using ViewRTU and then configure a few parameters in order to perform a desired function.

4.2 Database Organization

Points are the individual instances of software blocks. Examples include Whessoe Varec 1900 (MSTX) and SCALER points. In both cases the user configures the Config parameters and is provided real time data through the Dynamic parameters.

4.2.1 Point Format

Data parameters in the Tank Gate Interface are addressed using a "Type.Number.Parameter" format. For example, "MSTX.02.Level" refers to MSTX Tank Gauge #2's IEEE floating point level. This format and corresponding fields are described below.

The TYPE field represents the Point Type. There are many different point Types in the Tank Gate Interface, referred to generically as Tank Gate Interface Software Blocks. Some of the point types include the COM (Communications), SYS (System), MSTX (MSTX Tank Gauge) point types. Each Type performs a different function.

The NUMBER field represents the instance of the point type. For example, the AI point may have up to 32 instances, which are addressed using the NUMBER field. Each instance shares the same data structure definition, yet each point has unique data values. In the case of the AI software block, each point manages a single input channel.

The PARAMETER field represents the items in the data structure of the point type. Examples of parameters include Value, Status, PntRef and RawValue. This field is explained in greater detail in the following section.

4.2.2 Parameter Description

Each parameter is defined by its Parameter Class and Data Type. The following subsections describe Parameter Classes, Parameter Data Formats and Common Parameters.

Parameter Classes

Each parameter, such as Value or Channel, is classified as one of the following classes:

Parameter Class	Description
Config	Configuration parameters such as channel numbers, tags, descriptions, ranges, operating modes, point references, constants for formulas and timing information.
Dynamic	Real-time data such as the value or the status. Dynamic data is calculated or measured during point execution scans, which occur every 250 msec.

Parameter Class	Description
Command	Output command data
Constant	Weights & Measures parameter
Scratch	Temporary data that is typically hidden from the user
System	System data (should not be changed by the user)

The user-related parameters are the Config, Command and Dynamic parameters. These parameters are available in the Edit Point window of ViewRTU. The remaining parameters are internal to the Software Block.

Note ViewRTU inserts default values for the Config parameters when the point is first defined. It is usually only necessary to fill in a few configuration parameters, such as channel numbers, to configure references and to configure links to other points.

Parameter Data Formats

Data is stored in the Tank Gate Interface as one of the following formats:

Data Format	Description
Byte	8-bit value (–127 to 128)
Unsigned Byte	8-bit value (0 to 255)
Coded	Unsigned Integer representing a digital state such as 'On,' 'Off,' 'Open,' 'Closed,' etc.
Integer	16-bit value (–32766 to 32767)
Unsigned Integer	16-bit value (0 to 65535)
IEEE floating point	32-bit value with mantissa and exponent
Time	Unsigned Long Integer representing the number of milliseconds since Jan. 1, 1970.
Tag	ASCII character strings, variable in length. Used for Tag and Description parameters
Point Reference	Reference to a point parameter. Format is TYPE.NUMBER.PARAM where TYPE is AI, DI, DO, etc. NUMBER is point number, 0–255 PARAM is the parameter of interest, such as Value or Command. example: AI.00.Value
Unsigned Long Integer	32-bit value (0 to 4,294,967,295)
Pointer	32-bit value representing a pointer to another parameter or memory location.
Long Integer	32-bit value
Integer (Hex format)	Integer in Hex (0x0000 to 0xFFFF)
Time HH:MM:SS	Unsigned Long Integer representing the number of milliseconds since midnight.
Time MM/DD/YY	Unsigned Long Integer representing the number of milliseconds since Jan. 1, 1970.
Unsigned Long Integer (Hex format)	Unsigned Long Integer in Hex (0x00000000 to 0xFFFFFFFF)

Common Parameters

The following parameters are found in almost all point types. These parameters are described below:

PntChecksum Parameter

The PntChecksum is a CRC-16 checksum of the Configuration Parameters of a point. Most points have the PntChecksum parameter; a few like the CLK (Clock) Point, DIAG (Diagnostics) Point, and the register points (BREG, IREG, and DREG) do not. Any time a Configuration Parameter is changed, the Tank Gate Interface re-calculates the checksum. The PntChecksum is used at initialization to validate each point in the database.

PntStatus Parameter

The PntStatus parameter gives information about point execution. Refer to the information provided for each Software Block about the particular use of the PntStatus parameter.

Elapse Parameter

The Elapse parameter usually indicates the time of the last point execution. It is used as the basis for automatic Change of State notifications.

Value Parameter

The Value parameter indicates the real-time value of the point. In the case of DI points, the Value represents a Coded value (i.e., On, Off, Opened, Closed, etc.) AI points represent the Value in an IEEE floating point format. In most cases, the Value parameter is one of the most important parameters for a point.

Level & Temp Parameters

The Level & Temp parameters indicate the real-time tank level and temperature of the tank gauge point. There are many Software Blocks available in the Tank Gate Interface associated with tank gauge communications, including Software Blocks for every major tank gauge manufacturer.

4.3 Gathering Point Data

For Host to Tank Gate Interface communications, there are two primary methods for gathering point data. These methods are listed below:

4.3.1 Standard Request-Response Format

The Host issues scan requests, and the Tank Gate Interface responds with the data.

The Scan method has the advantage of being deterministic, the response time to a particular request will always be the same.

This method has the limitation that if there are many points defined in the Tank Gate Interface, it often takes several requests to obtain all of the data. Most of the time data has not changed since the last request, so this results in inefficiencies in update times. This situation is often the case in systems where there are many digital points that do not change frequently.

4.3.2 Change of State Format

The Host issues scan requests based on a Change of State condition. Some systems refer to this as Event Mode. The Tank Gate Interface keeps track of the items that have changed since the last Host request. The Host can issue a single request of 'tell me what has changed since my last request.' The Tank Gate Interface will respond with the results, which include addressing information about the data. In a typical system, this results in a significant improvement in the throughput rate for data.

When FuelsManager is the Host system, the Change of State method has the advantage of being very efficient. Only the data that has changed is reported. Change of State is not available when using Modbus.

4.3.3 Change of State-Related Parameters

In order to support the Change of State method, many points have additional configuration parameters included.

Parameter	Description
Value	One of the parameters which will be returned to a Change of State request by the Host. Most Software Blocks are designed so that the Value parameter is the main parameter of interest.
Report	Is used for Change of State processing only Causes automatic notification to the Host (in response to a Change of State Request) when the Value Changes State. Valid values are High, Low or No. Report = No disables notification. Points with Report = High have higher priority than points with Report = Low.
Maxtime	Is used for Change of State processing only Specifies the maximum time (in secs) between automatic Change of State data being sent to the Host in response to a Change of State Request. When the Maxtime period expires, the Value to is forced appear as if it has changed even if it has not, ensuring that data is sent to the host periodically. Setting Maxtime to 0 disables this option. The maximum is 255 seconds.
Deadband LevelDeadband TempDeadband	Affects the Change of State processing. It allows users to filter out insignificant changes, freeing the communications link to send other data.

Note Not all Host protocols support the Change of State method. The RTU Slave protocol used with FuelsManager supports either method.

Note The Modbus protocol is Scan-based. Therefore, the Report and Maxtime parameters have no meaning.

4.3.4 Modbus Communications

Some versions of the Tank Gate Interface are capable of communicating with Modbus compatible devices with both Modbus Masters and Slave devices. The Tank Gate Interface is flexible, allowing communications with devices that strictly comply with the Modicon Modbus protocol, as well as devices with more advanced Modbus implementations such as Honeywell's APM-SIO.

The Modbus Slave protocol handler responds to read and write requests from a Modbus master system. A detailed description of the Modbus Slave protocol handlers follows.

Modbus Slave

The Modbus Slave protocol handler is enabled by setting the Protocol parameter of a COM point to Modbus Slave. COM 0 of the Tank Gate Interface is auto sensing. If a Modbus Master requests data from the Tank Gate Interface, the Tank Gate Interface will automatically detect that Modbus is being used and invoke the Modbus Slave protocol handler. The Modbus Slave protocol handler responds to requests from Modbus masters. A MODGW point is automatically created to provide user access to the operation of the protocol handler. The MODGW point also provides dynamic information about the communications requests from the Modbus master.

The Modbus Slave protocol handler is flexible, allowing the user to set options for handling several aspects of Modbus communications. The Modbus Slave uses the GWBLK Gateway Block as a lookup table for data addresses.

The Gateway Block allows the user to specify data address and point reference combinations. This allows the Tank Gate Interface to be used with an existing system that is already configured. The user defines a GWBLK point and specifies which parameter in the Tank Gate Interface will be used for a particular address. When a request from a master is received, the Modbus Slave protocol handler will first search for any GWBLK points and determine if the data address of the request is specified in one of the GWBLK points. If the data address is contained in a GWBLK point, then the corresponding point reference is used to provide the data for the reply to the master.

COM 0 will automatically sense whether the host system is ViewRTU or a Modbus Master. The communications parameters for COM 0 are 9600 baud, 8 data bits and No Parity. When switching between ViewRTU and Modbus communications, it is necessary to wait 60 seconds for the current protocol to time-out. The Tank Gate Interface will go back to the auto sensing mode and wait for a request. When a request is received, the Tank Gate Interface will determine if the request is from ViewRTU or a Modbus Master. If the Tank Gate Interface has problems switching, press the Reset button and this will force the Tank Gate Interface back into the auto sensing mode.

Note COM 1 (if available) is always a Modbus Slave. The communications parameters for COM 1 are 9600 baud, 8 data bits and No Parity. COM1 is not available on the 8315 Tank Gate Interface

Note The Tank Gate Interface uses the ID switch in determining to which address on the communications bus to respond.

Tank Gate Interface responds to the following Function Codes:

Function Code	Description	Comments
3	Read Output Register	FC 3 and FC 4 are treated the same. Use either FC 3 or FC 4 to read data from the Tank Gate Interface
4	Read Input Register	
5	Force Single Output Status	FC 4 and FC 6 are treated the same. Use either FC 5 or FC 6 to write data to the Tank Gate Interface
6	Preset Single Register	
15	Force Multiple Outputs	FC 15 and FC 16 are treated the same. Use either FC 15 or FC 16 to write multiple registers to the Tank Gate Interface
16	Preset Multiple Registers	

There are two methods for data addressing within the Tank Gate Interface

- The Tank Gate Interface has a fixed Modbus Map of selected parameters
- Gateway Block (GWBLK) software blocks can be configured to set the data address

4.3.5 Fixed Modbus Map

For each version of the Tank Gate Interface, there is a fixed map of data registers. A partial example is shown below:

Address	Type	Number	Parameter	Data Type
5000	MSTX	0	Command	CODED
5001	MSTX	0	Level	REAL
5003	MSTX	0	Temp	REAL
5005	MSTX	0	Value	REAL
5007	MSTX	0	Status	HEX
5008	MSTX	0	PntStatus	IHEX
5009	MSTX	0	Elapse	TIME
5011	MSTX	1	Command	CODED
5012	MSTX	1	Level	REAL
5014	MSTX	1	Temp	REAL
5016	MSTX	1	Value	REAL
5018	MSTX	1	Status	HEX
5019	MSTX	1	PntStatus	IHEX
5020	MSTX	1	Elapse	TIME

Table 4-1: Fixed map of data registers

4.3.6 GWBLK method

The GWBLK is the preferred means to address data in the Tank Gate Interface. The GWBLK has a great deal of flexibility. Data can be scaled, or grouped using the GWBLK. The Gateway Block (GWBLK) allows the user to specify data address and point reference combinations. This allows the Tank Gate Interface to be used with an existing system that is already configured. The Tank Gate Interface can be tailored to meet the needs of the Host. In some cases, the Host system may have some constraints in the use of its Modbus scanner that make it necessary to use a GWBLK. In this mode, the user defines a GWBLK point and specifies which database parameter will correspond to a particular data address. When a request from a master is received, the Modbus Slave protocol handler will first search for any GWBLK points and determine if the data address of the request is specified in one of the GWBLK points. If the data address is contained in a GWBLK point, then the corresponding point reference is used to provide the data for the reply to the master. If the data address is not in any GWBLK point, then data will be read using the prevailing Address Mode.

The Gateway Block (GWBLK) allows the user to specify data address and point reference combinations. The GWBLK acts as a lookup table for data items in the Tank Gate Interface. The user defines a GWBLK point and specifies which database parameter will correspond to a particular data address. When a request from a master is received, the Modbus Slave protocol handler will search for any GWBLK points and determine if the data address of the request is specified in one of the GWBLK points. If the data address is contained in a GWBLK point, then the corresponding point reference is used to provide the data for the reply to the master.

The procedure for using the GWBLK is given below:

- Add a GWBLK point. Depending upon the addressing requirements of the host system, it may be necessary to add additional GWBLKs.
- Configure the GWBLK by setting the Address, PntRef and Size parameters to the parameters of interest in the Tank Gate Interface. Refer to the following examples:

EDIT POINT

Point Help

Current Point # Point Desc: GWBLK.00 : Address Block Gateway

CONFIG

Tag	Point Tag	Lookup Table
Protocol	Protocol to use GWBLK with	MODBUS Slave
ComPort	ComPort Mask	0xFF
DataMode	0=default, 1=Conv to Integer	0x0000
RegSet	Register Set size	0
Offset	Input Zero	0.0
Scale	Input Full Scale	0.0
ValueMin	Output Zero	0.0
ValueMax	Output Full Scale	0.0
CommFailValue	Value for Comm Failures	0.0

DYNAMIC/COMMAND

PntStatus	Point Status	0
PntChecksum	Point CheckSum	0x0000

Buttons: Minimize, Next, Examine, Download, Connections, Previous, Exit, Upload

Figure 4-2: Adding a GWBLK point in View RTU

EDIT POINT

Point Help

Current Point # Point Desc: GWBLK.00 : Address Block Gateway

CONFIG

Addr1	Register Address	100
PntRef1	Input Reference1	WV1900.00.Level
Size1	Block#1 Size (#params)	20
Filter1	Comm Fail Test Filter1	0x0000
Addr2	Register Address	200
PntRef2	Input Reference2	WV1900.00.Temp
Size2	Block#2 Size (#params)	20
Filter2	Comm Fail Test Filter2	0x0000
Addr3	Register Address	300
PntRef3	Input Reference3	WV1900.00.PntStatus

DYNAMIC/COMMAND

PntStatus	Point Status	0
PntChecksum	Point CheckSum	0x0000

Buttons: Minimize, Next, Examine, Download, Connections, Previous, Exit, Upload

Figure 4-3: Configure the GWBLK in View RTU

In this example, the Modbus register map is configured according to the following table:

Data Address	Parameter	Comments
100-101	MSTX.00.Level	Level is in IEEE Floating point format.
102-103	MSTX.01.Level	
104-105	MSTX.02.Level	
.	.	
.	.	
.	.	
138-139	MSTX.19.Level	
200-201	MSTX.00.Temp	Temperature is in IEEE Floating Point Format.
202-203	MSTX.01.Temp	
204-205	MSTX.02.Temp	
.	.	
.	.	
.	.	
238-239	MSTX.19.Temp	
300	MSTX.00.PntStatus	PntStatus is in Integer format.
301	MSTX.01.PntStatus	
302	MSTX.02.PntStatus	
.	.	
.	.	
.	.	
.319	.MSTX.19.PntStatus	

Table 4-2: Example Modbus register map

4.4 Common Software Blocks

This section describes Software Blocks included with the base unit of the 8312 TGI.

4.4.1 Clock (CLK)



The Clock point provides access to the System Clock. Standard time format is in the form of MM/DD/YY HH:MM:SS.

Parameters

The database parameters used by the CLK point are listed and described below:

Configuration Parameters	Function
TZ	Time Zone string

Dynamic Parameters	Function
SysTime	System Time in the form MM/DD/YY HH:MM:SS. Writing to this value will change the system time
SysTicks	Time in "ticks" format. Ticks are incremented every 10 msec, with the initial value of 0 equal to Jan. 1, 1970 at 00:00:00.
timezone	Time zone relative to GMT. The timezone is entered in seconds. Example: Eastern Time Zone = 18000; Pacific = 28800
daylight	Daylight Saving Flag

4.4.2 Communications (COM)



The Communications point reports the status and controls the operation of the communications interfaces. COM points are automatically created by the system at initialization.

Parameters

The database parameters used by the COM point are listed and described below:

Configuration Parameters	Function
Protocol	Protocol handler assigned to the ComPort. Valid values are: Disabled RTU Slave Modbus Slave TSU Slave The defaults are: COM 0: RTU Slave – 9600 Baud COM 1: Modbus Slave– 9600 Baud
Mode	The Mode parameter is used in conjunction with the Protocol. Different protocols will use the Mode in different ways, depending on the needs of the protocol.
ComPort	Communications Port number. Valid values are 0–3. You should never modify the ComPort parameter.

Configuration Parameters	Function
BaudRate	Baud Rate for communications to either the Host or Slave system. Valid values are: 1200, 2400, 4800, 9600, 19200. Changing the BaudRate parameter will immediately change the configuration of the ComPort. The default is 9600.
ComParams	Defines the number of data bits and the parity used by the com port. Examples include: 8O – 8 Data Bits Odd Parity 8E – 8 Data Bits, Even Parity 8N – 8 Data Bits, No Parity 7O – 7 Data Bits, Odd Parity 7E – 7 Data Bits, Even Parity 7N – 7 Data Bits, No Parity TI – TIWAY The default is '8N'.
TimeOut	Time in seconds that indicates a time-out of communications. If no Host or Slave communications is received for the length of time specified by the TimeOut, the CommStatus parameter will indicate Off Line and communications failure processing will take place.
ErrCheck	Error checking used by the protocol. Valid values are: LRC – Longitudinal Redundancy Check CRC – Cyclical Redundancy Check
RespDelay	Time in milliseconds for which the 8303 TGI will delay a response to the Host. The default is 50 msec.
SynchMax	The SynchMax is used by some slave protocols for autosynchronization of the BaudRate. The SynchMax is used to determine if the BaudRate is correct. If the SynchMax is zero, then no synchronization is attempted.
DirectPort	The DirectPort is used then the Protocol is set to Direct.

Dynamic Parameters	Function
CommStatus	Coded variable indicating the On-line/Offline status of the COM point.
State	Current state of the message being sent/received.
Command	Current command being processed.
Status	Status if the last message.
CommErrors	The number of communication errors.
NumTrans	The number of transactions.
Elapse	Time of the last Change of State.
PntChecksum	CRC-16 Checksum of point's static Configuration Parameters.

Application

The COM point controls the operation of Host and Slave communications. The Baud Rate, Communications Parameters and Protocol may be changed by assigning values to the appropriate parameter. Each Com port is independent of the other and completely flexible in its use.

For example, you may configure the system to communicate with a single host redundantly using the same protocol. Alternatively, the 8300 series Tank Gate Interface can communicate to different hosts using different protocols, allowing the 8300 series Tank Gate Interface to act as a bridge. Other options include assigning one COM point to communicate with a Slave device while communicating to a Host system on the other.

4.4.3 Floating Point Register (FPREG)



The Floating Register point provides four bytes of storage in IEEE floating point format. It is often used for inter-point communications where no other means is provided.

Parameters

The database parameters used by the FPREG point are listed and described below:

Configuration Parameters	Function
Tag	Point tag

Dynamic Parameters	Function
Value1 through Value50	Real (4 bytes) value
PntStatus	Integer HEX value indicating status of point. Values are: 0x0001: Gauge Not Responding. The first time the gauge does not respond, the 0x8000 bit is set. On the second try, the 0x01 bit is set. 0x0002: Data Invalid (General Data Error) 0x0004: Bad Level 0x0008: Temp OverRange 0x0010: Temp UnderRange 0x0020: A/D Error 0x0040: Filtering Level 0x0800: Filtering Temp
Elapse	Time of the last Change of State.
PntChecksum	CRC-16 Checksum for point's static Configuration Parameters.

4.4.4 Emulator (EMU)



The Emulator point allows the to emulate a Whessoe-Varec Model 6820 Tank Scanning Unit (TSU). This point provides access for level, temperature data, and gauge status information from any type of tank gauge interface supported by the 8203 Dual RS-485 Communications Interface Module.

Parameters

The database parameters used by the EMU point are listed and described below:

Configuration Parameters	Function
Tag	The point description can contain 30 bytes of data and can include any printable ASCII character. Descriptions can be used as information relevant to any aspect of the point, such as its use, location, operating information, etc. The default description is set to "EMU.00".
LevelUnits	Specifies the engineering units for the level data. F: feet, m: Millimeters M: Meters I: Inches P: ft-in-16ths The LevelUnits need to match the units specified during the gauge setup.

Configuration Parameters	Function
TempUnits	Specifies the engineering units for the temperature data. TempUnits Specifies the engineering units for the temperature data. F: Fahrenheit C: Celsius The TempUnits needs to match the units specified during the gauge setup.
DensityUnits	Specifies the engineering units for the density data. DensityUnits Specifies the engineering units for the density data. K: kg/m ³ A: API L=lbs/cu ft The DensityUnits needs to match the units specified during the gauge setup.
Offset	Specifies the offset to the first address.
PntRef1 – 20	Input point reference for the EMU point to monitor. The PntRef parameter is set to the Level parameter for the tank gauge point. The temperature will be read at the same time as the level. The EMU point interfaces tank gauge interface points: WV1900 – Whessoe–Varec Model 1900

Dynamic Parameters	Function
PntStatus	Byte value indicating status of point Values are: Dynamic ParametersFunction PntStatusByte value indicating status of point Values are: 0: No error 15: Invalid Type for PntRef 16 Invalid Number for PntRef 17 Invalid Param for PntRef 19: PntRef point does not exist 25: PntRef is not defined
PntChecksum	CRC–16 Checksum for point's static Configuration parameters.

Application

The Emulator point (EMU) provides a communication interface between older tank gauging system and point blocks within the 8203 Dual RS–485 Communications Interface Module . Currently, the 8203 Dual RS–485 Communications Interface Module can emulate a Whessoe Varec Model 6810 Tank Scanning Unit (TSU).

The EMU point associates a tank gauge point with an address to be used by TankView. EMU.0 provides point references for TankView System Addresses 1–50. EMU.1 is associated with System Addresses 51–100. A EMUGW gateway point is automatically created when the protocol for a COM point is set to TSU Slave.

4.4.5 EMU Gateway (EMUGW)



The EMU Gateway point is used to manage scanning functions for the EMU point. Statistics are maintained for the communications between the Series 8130 and the tank gauging software (TankView or System IV). Special firmware is required on the 8203 Dual RS-485 Communications Interface Module to support the emulation functions.

Parameters

The database parameters used by the EMUGW point are listed and described below:

Configuration Parameters	Function
Protocol	Protocol to emulate. Valid values are: TSU Slave
ID	Address to respond to
Mode	Operational Mode
BaudRate	Baud Rate used to communicate with TankView
ComParams	Defines the number of data bits and the parity used by the com port. Examples include: ID: Address to respond to Mode: Operational Mode BaudRate: Baud Rate used to communicate with TankView ComParams Defines the number of data bits and the parity used by the com port. Examples include: 8O – 8 Data Bits Odd Parity 8E – 8 Data Bits, Even Parity 8N – 8 Data Bits, No Parity 7O – 7 Data Bits, Odd Parity 7E – 7 Data Bits, Even Parity 7N – 7 Data Bits, No Parity The default is '8N'.
LevelConvert	Determines the units in which the level data will be displayed. F: feet, M: Millimeters. If no value is specified, no conversion will be performed.
TempConvert	Determines the units in which the temperature data will be displayed. F: Fahrenheit, C: Celsius. If no value is specified, no conversion will be performed.
DensityConvert	Determines the units in which the density data will be displayed. A: API, L: lbs/cu ft, K: kgs/m ³ . If no value is specified, no conversion will be performed.

Dynamic Parameters	Function
Message	Hex representation of the request sent by the host
Command	Current Command
Addr	Displays the tank number of the currently selected tank.

Dynamic Parameters	Function
LevelRef	The reference point for level and temperature data for the tank currently requested by TankView
Flags	Hex value representing the operational status
NumRequests	Number of requests from TankView or Entis
NumComErrors	Number of errors
Elaspe	Time of last request
PntChecksum	CRC-16 Checksum for point's static Configuration Parameters.

Application

The EMUGW point is automatically created when the TankView (TSU Slave) protocol is initiated. In order to use the TSU Slave protocol, set the Protocol parameter of the COM point to TSU Slave. At that time, an EMUGW and an EMU point will be created to provide a user interface for configuration and control of communications with TankView or System IV. The baud rate and data link parameters are set in the COM point as well. The default is 9600, 8 data bits, No parity.

The EMUGW point keeps track of the number of requests and number of errors associated with the EMU Slave protocol. The current tank number (ID) and the point associated with the tank number (LevelRef) are updated as requests from TankView are processed. The PntRefs correlate to the SYS ADR parameter in TankView or IDs in System IV.

4.4.6 Gateway Block (GWBLK)



The Gateway Block point is used for compatibility with Modbus Master devices. Rather, you configure a GWBLK to function as a look-up table. The GWBLK point lets you specify which point references will respond to data addresses in the request from a Host. The GWBLK point contains a cross-reference table for database parameters and data addresses.

Parameters

The database parameters used by the GWBLK point are listed and described below:

Configuration Parameters	Function
Tag	A Tag can contain 15 bytes of data and can include any printable ASCII character. Tags can be used to identify points indicating the use of the point such as "Modbus Slave" or "Register Value1." The default tag is set to "GWBLK.00".
Protocol	Protocol that the GWBLK point is used with. Valid values are: Modbus Slave
ComPort	Bit mask to enable address referencing. If a bit corresponding to the com port, then address referencing is enabled for the channel. The default is 0xFF (all COM ports).

Configuration Parameters	Function
DataMode	Integer HEX value that controls the data returned to a Modbus Host 0: Use parameter values 0x01: Convert to Integer 0x02: Return 0xFF if the data is invalid. 0x04: Convert to Integer using only the Scale If the DataMode is 0x01, the PntRef data will be converted to an integer using the Offset, Scale, ValueMin and ValueMax. If the DataMode is 0x04, the Scale parameter is used to convert to an integer.
RegSet	Register Set size
Offset	Input range Offset used for scaling the output to an integer value when DataMode=1.
Scale	Input range Scale used for scaling the output to an integer value when DataMode=1.
ValueMin	Output range Offset used for scaling the output to an integer value when DataMode=1.
ValueMax	Output range Scale used for scaling the output to an integer value when DataMode=1.
CommFailValue	Value to set all of the output registers to when there is a communications or other failure. The CommFailValue works in conjunction with the Filter values. If the PntStatus of the PntRef has bits set that match the Filter, the reference value is declared invalid and the output value will be set to the CommFailValue. This mode is overridden by DataMode = 0x02.
Addr1-10 PntRef1-10 Size1-10 Filter1-10	Addr1 is the Data Address and PntRef1 is the corresponding database parameter that will be used for a response. The default Size is 1. See the discussion below for more detail on the Size parameter. The Filter is used to determine if the data is valid. The PntStatus of the point specified by the PntRef is read and if there are bits set that match the Filter, the source data is considered invalid. The output registers will be set to the value determined by the CommFailValue.

Dynamic Parameters	Function
PntStatus	Byte value indicating status of point Values are: 0: No error
pntChecksum	CRC-16 Checksum of point's static Configuration Parameters

Application

The GWBLK point is a look-up table used by the Modbus Slave protocol handler. Up to sixteen address-point reference pairs may be used per GWBLK point. Multiple GWBLK points may be used if necessary. The Addr parameter specifies the data address. The corresponding PntRef parameter specifies the database parameter for the request. The Gateway Block point allows you to use the 8300 series Tank Gate Interface easily in retrofit applications. It is not necessary to re-configure an existing HMI or Host system. You can configure the 8300 series Tank Gate Interface to match the addresses used in the Host system.

When the Modbus Slave protocol handler receives a request, it searches the GWBLK points to determine if any of the Addr parameters match the request. If a match is found, the data referenced by the PntRef parameter will be used for the response.

There are three data modes: DataMode=0, which returns the data in the default format, and DataMode=1, which returns the data in an integer format. DataMode=1 will scale IEEE floating point data to an integer value, using the Offset, Scale, ValueMin and ValueMax parameters. If DataMode = 4, the data will be scaled to an integer by multiplying the data value times the Scale parameter.

The DataMode can also control if the data is changed to 0xFFFF if the data is invalid. The Filter parameter is compared to the PntStatus of the PntRef parameter. If bits in the PntStatus match bits in the Filter, the data is considered invalid and the a read from a modbus host will result in the data being set to 0xFFFF.

When Block Read or Write requests are received, then the way in which the Modbus Slave protocol handler responds is determined by the Size parameter.

Size Parameter

A range of addresses can be specified by setting the Size parameter. This sets the indexing mode to Number Indexing, which means that Block Read/Write requests from the Hosts are handled by stepping through the points number by number. For example, if Addr1 is 100, and PntRef1 is MSTX.00.RawValue, then a Block Read to address 100 with a length of 8 will return the values, MSTX.00.RawValue, MSTX.01.RawValue, ... MSTX.07.RawValue. Setting the Size to 1 does not limit the read to 1 parameter, rather it indicates that block operations will be processed by stepping through points by incrementing the number, starting with parameter specified by the PntRef.

4.4.7 Integer Register (IREG)



The Integer Register point provides two bytes of storage. It is often used for inter-point communications where no other means is provided.

Parameters

The database parameters used by the IREG point are listed and described below:

Configuration Parameters	Function
Tag	A Tag can contain 15 bytes of data and can include any printable ASCII character. Tags can be used to identify points indicating the use of the point.

Dynamic Parameters	Function
Value	Integer (2 bytes) value

4.4.8 Modbus Gateway (MODGW)



The Modbus Gateway provides dynamic and statistical information for the communications between the 8300 series Tank Gate Interface and the Modbus masters.

Parameters

The database parameters used by the MODGW point are listed and described below:

Configuration Parameters	Function
ID	Slave Address that the Modbus Slave protocol handler will respond to. The default is to match the Unit Address of the 8300 series Tank Gate Interface.
Mode	Operational Mode. The Mode is a hex value, with individual bits controlling various aspects of the operation of the Modbus Slave protocol handler. The bits have the following meanings: 0x01 – Set Param Indexing mode 0x02 – Integer Swap mode 0x04 – Swap CRC bytes 0x08 – ASCII mode 0x20 – Wonderware Mode 0x80 – Ignore any trailing nulls in the request The default is 0.
BaudRate	Baud Rate for communications to the Host system. Valid values are: 1200, 2400, 2400, 9600 and 19200. Changing the BaudRate parameter will immediately change the configuration of the ComPort.
ComParams	Defines the number of data bits and the parity used by the com port. Valid values include: 8N – 8 data bits, No parity 8O – 8 data bits, Odd parity 8E – 8 data bits, Even parity 7O – 7 data bits, Odd parity 7E – 7 data bits, Even parity The default is '8N'.
DetectTime	Modbus RTU Mode character timer (in 1/100s of a second).

Dynamic Parameters	Function
Message	Current request message, displayed in hex format.
Command	Current command. Values include: 1 – Read Output Status 2 – Read Input Status 3 – Read Output Registers 4 – Read Input Registers 5 – Force Single Coil 6 – Preset Single Register 15 – Force Multiple Coils 16 – Preset Multiple Registers
Addr	Data Address for current request.
Elapse	Time of the last request from the master
PntChecksum	CRC-16 Checksum of point's static Configuration Parameters

Application

The MODGW point provides status information for the communications with any Modbus masters used with the 8300 series Tank Gate Interface. On the 8300 series Tank Gate Interface Motherboard, the MODGW point is created automatically whenever the Modbus Slave protocol is defined for a COM point. The point number created will correspond to the ComPort such that MODGW.1 is created for COM 1. Use the Upload command from the Config Menu to retrieve the data from the MODGW point or any other points created automatically by the RTU.

The MODGW point provides information about the current command and data address requested by the Modbus master system. The MODGW provides assurance that requests are being received and processed.

4.4.9 Scaler Point (SCALER)



The Generic Scaling point allows you to perform math functions in the 8300 series Tank Gate Interface. The SCALER point monitors one or more database reference values and performs an equation in the form:

$$\text{Value} = Ax + By + Cz + K$$

Note A, B, C & K are user-entered constants.

Note x, y & z are inputs from other database points.

Parameters

The database parameters used by the SCALER point are listed and described below:

Configuration Parameters	Function
Tag	A Tag can contain 15 bytes of data and can include any printable ASCII character. Tags can be used to identify points indicating the use of the point such as "Eng Converter". The default tag is set to "SCALER.00".
PntRef1 PntRef2 PntRef3	The PntRef parameters determine the input source for the SCALER point to monitor. Up to three references may be specified. RefValue1 is the X term, PntRef2 is the Y term, and PntRef3 is the Z term. If a reference is not specified, then it is not used in the equation.
A	Constant that is multiplied with RefValue1
B	Constant that is multiplied with RefValue2
C	Constant that is multiplied with RefValue3
K	Constant K
Deadband	Change of State deadband
Report	Causes automatic notification to the Host (in response to a Change of State Request) when the Value changes State. Parameter value can be High, Low or No. Report=No disables notification. Points with Report = High will be sent before points with Report = Low. The default is No.
Maxtime	Specifies the maximum time (in secs) between automatic Change of State responses being sent to the Host. Report must be set to either Low or High for the Value parameter to be sent in response to a Change of State Request. A value of 0 disables this option. Non-zero values cause responses to be sent although the value may have not changed since the last message. The default is 60.

Dynamic Parameters	Function
Value	Output value for the SCALER point. Value = Ax + By + Cz + K. x corresponds the RefValue1, y is RefValue2, and z is RefValue3.
RefValue1 RefValue2 RefValue3	RefValue1 – 3 are the values of the PntRef1 – 3 parameter references. The references can be to any point that produces a floating point value.
Value1	Value parameter converted to Integer format

Dynamic Parameters	Function
PntStatus	Byte value indicating status of point Values are: 0: No error 15: Invalid Type for PntRef 16 Invalid Number for PntRef 17 Invalid Param for PntRef 19: PntRef point does not exist 25: PntRef is not defined
Elapse	Time the SCALER point last executed.
PntChecksum	CRC-16 Checksum of point's static Configuration Parameters

Application

The SCALER point allows you to perform simple math functions such as conversion of units. The SCALER point takes the value from user-specified database references, multiplies each by a constant and adds the three product terms. A constant K may also be factored in. The SCALER point works in conjunction with parameters that are in floating point format.

4.4.10 System Information (SYS)



The System Information Point lists the hardware and software specifications of the system. Other information includes the hardware version and any connected devices.

Parameters

The database parameters used by the SYS point are listed and described below:

Configuration Parameters	Function
RTUTag	RTUTag can contain 15 bytes of data and can include any printable ASCII character.
DBFile	The database file name. DBFile is the name of the RCF database configuration file
DBVer	The database version.
PntEnable	Disable/Enable execution of points. Default is Enable.

Dynamic Parameters	Function
UnitAddr	The Unit Address (SW1) for the 8300 series Tank Gate Interface.
DBPnts	The number of database points defined.
DBSize	The size of the database in bytes.
DBChangeTime	The time of last database modification.
SysVer	The firmware version.
SysChecksum	The system checksum.
HardVer	The PCB hardware version.
PSDVer	The programmable logic version.
PntChecksum	CRC-16 Checksum for point's static Configuration Parameters.

5 SAAB TRL/2 Software Blocks

This chapter describes the Software Blocks that are included in the 8312 Tank Gate Interface (SAAB TRL/2), excluding those common to all the 8300 TGI software versions. The Software Blocks are listed in alphabetical order by acronym.

Common Software Blocks are described in section 4.4 on page 29.

5.1 Saab Data Acquisition Unit (DAU)



The Saab Data Acquisition Unit point provides an interface to Saab Model 2100 Data Acquisition Units. The DAU point interfaces to Saab DAUs using Modbus through a Saab FCU. The 8203 Dual RS-485 Interface Module is used to connect to the FCU. The 8212 Saab (TRL/2) Communications Interface Module is used to directly connect to the DAU over the TRL/2 bus.

5.1.1 Parameters

The database parameters used by the DAU point are listed and described below:

Configuration Parameters	Function
Tag	A Tag can contain 15 bytes of data and can include any printable ASCII character. Tags can be used to identify the name of the tank being monitored. The default tag is set to "DAU.00".
Description	The point description can contain 30 bytes of data and can include any printable ASCII character. Descriptions can be used as information relevant to any aspect of the point, such as its use, location, operating information, etc. The default description is set to "DAU.00"
Module	Not Used.
Chan	Physical channel number to which the DAU is connected. On the 8203 Dual RS-485 Communications Interface Module, the Chan can be set to 1 or 2.
ID	Physical Address of the Data Acquisition Unit (0-999).
Addr	FCU Address (if Mode = 0x02)
Mode	Operational Mode. Values are: 0x01: Swap Mode 0x02: Communication via FCU 0x04: Read REX Temperature 0x08: FCU – Read 0x8000 Data Addresses 0x10: SAAB Swap Mode 0x80: ASCII Mode
BaudRate	Baud Rate for communications to the DAU device. Valid values are: 1200, 2400, and 4800.
ComParams	Defines the number of data bits and the parity used by the com port. Valid values include: 8N – 8 data bits, No parity 8O – 8 data bits, Odd parity 8E – 8 data bits, Even parity 7O – 7 data bits, Odd parity 7E – 7 data bits, Even parity The default is 8N.

Configuration Parameters	Function
TempUnits	Specifies the engineering units for the temperature data read from the DAU. F: Fahrenheit C: Celsius The TempUnits needs to match the units specified during the DAU setup. The default is C
TempConvert	Determines the units in which the temperature data will be displayed. F: Fahrenheit C: Celsius If no value is specified, no conversion will be performed. The default is C
TempDeadband	Specifies the amount of change in the Temp that must occur for the level to be updated each Change of State period. The default is 0.25.
TempInterleave	Temperature Interleave. Determines how often the temperature is read from the DAU. The default is 10, which means that every tenth scan of the DAU, the temperatures will be read.
Report	Causes automatic notification to the Host (in response to a Change of State Request) when the Value changes State. Parameter value can be High, Low or No. Report=No disables notification. Points with Report = High will be sent before points with Report = Low. The default is High.
Maxtime	Specifies the maximum time (in secs) between automatic Change of State responses being sent to the Host. Report must be set to either Low or High for the Value parameter to be sent in response to a Change of State Request. A value of 0 disables this option. Non-zero values cause responses to be sent even if the value has not changed since the last message. The maximum is 65535 seconds. The default is 240.
Watchdog	Enables the Motherboard watchdog task for the DAU point. The watchdog task monitors the DAU point and verifies it is scanning for devices. If the DAU point stops execution, the PntStatus will be set to 0x4000 to indicate a failure.

Dynamic Parameters	Function
Temp1–Temp14	Floating point value representing the temperature of each temp sensor configured.
TempFilter	<p>Temp in Liquid parameter. Bits 0 – 13 indicate if Temp sensors 1 – 14 are submerged in liquid. Bit 14 indicates a System Error. Bit 15 indicates a Temp calibration error.</p> <p>0x0001: Temp 1 is in Liquid 0x0002: Temp 2 is in Liquid 0x0004: Temp 3 is in Liquid 0x0008: Temp 4 is in Liquid 0x0010: Temp 5 is in Liquid 0x0020: Temp 6 is in Liquid 0x0040: Temp 7 is in Liquid 0x0080: Temp 8 is in Liquid 0x0100: Temp 9 is in Liquid 0x0200: Temp 10 is in Liquid 0x0400: Temp 11 is in Liquid 0x0800: Temp 12 is in Liquid 0x1000: Temp 13 is in Liquid 0x2000: Temp 14 is in Liquid 0x4000: System Error 0x8000: Temp Calibration error</p>
TempStatus	<p>Temp status parameter (blocked). This parameter indicates the blocked status of each temperature sensor.</p> <p>0x0001: Temp 1 blocked 0x0002: Temp 2 blocked 0x0004: Temp 3 blocked 0x0008: Temp 4 blocked 0x0010: Temp 5 blocked 0x0020: Temp 6 blocked 0x0040: Temp 7 blocked 0x0080: Temp 8 blocked 0x0100: Temp 9 blocked 0x0200: Temp 10 blocked 0x0400: Temp 11 blocked 0x0800: Temp 12 blocked 0x1000: Temp 13 blocked 0x2000: Temp 14 blocked 0x4000: Legal NMI–temperature 0x8000: NMI approved DAU</p>

Dynamic Parameters	Function
TempDiagCode	Temp diagnostic code parameter. This parameter indicates the error status of each temperature sensor. 0x0001: Temp 1 error 0x0002: Temp 2 error 0x0004: Temp 3 error 0x0008: Temp 4 error 0x0010: Temp 5 error 0x0020: Temp 6 error 0x0040: Temp 7 error 0x0080: Temp 8 error 0x0100: Temp 9 error 0x0200: Temp 10 error 0x0400: Temp 11 error 0x0800: Temp 12 error 0x1000: Temp 13 error 0x2000: Temp 14 error 0x4000: Master (set if using an FCU and DAU does not respond) 0x8000: Temp average error. No temperature sensor is in liquid.
AvgTemp	Floating point value representing the average tank temperature. This value is the average of all sensors below the liquid level.
PntStatus	Integer HEX value indicating status of point. Values are: 0x0001: DAU Not Responding 0x0010: No response (set if using an FCU and DAU does not respond) 0x4000: Failure of the 8203 or 8212 module. This bit is set if the Watchdog task on the Motherboard determines that the 8203 or 8212 module has stopped updating.
Elapse	Time of the last scan
PntChecksum	CRC-16 Checksum for point's static Configuration Parameters

5.1.2 Application

The DAU point provides an interface to Saab Data Acquisition Units (DAU) via an FCU, using a 8203 Dual RS-485 Communications Interface Module or the 8212 Saab (TRL/2) Communications Interface Module.

If the Data Acquisition Units are connected to a Saab FCU, then an 8203 Dual RS-485 Communications Interface Module or the 8212 Saab (TRL/2) Communications Interface Module is used to read data. The 8203 Dual RS-485 Communications Interface Module or the 8212 Saab (TRL/2) Communications Interface Module automatically detects startup, and an MSCAN point is automatically created to manage the scanning task. Chan determines which Channel is used for communications to the slave device. The Chan parameter must match the channel used to communicate with the Saab DAU.

A DAU point is needed for each DAU connected to the 8303 TGI or the 8212 Saab (TRL/2) Communications Interface Module. The ID must match the unit address of the Saab DAU. The BaudRate and ComParams values must match the communications parameters of the Data Acquisition Unit. The communications parameters are set as each DAU point is processed.

8203 TGI or the 8212 Saab (TRL/2) Communications Interface Module software points may begin scanning when the point is created, or when the correct Channel number is assigned. Which of these events begins the scanning process varies with each point.

The DAU point works in conjunction with the Modbus Master protocol handler (MSCAN). MSCAN points are automatically created so you only have to set the Chan, BaudRate, ComParams and ID parameters in order to establish communications with the Saab DAU.

The Mode parameter determines whether the DAU point reads the data from the Saab FCU's holding registers. If the Mode is 0x02, then the data is read from the holding registers. The Addr parameter determines the FCU address and the ID is not used. If the Mode is 0, then the FCU sends the request to the DAU and sends the response back to the 8303 TGI or the 8212 Saab (TRL/2) Communications Interface Module. The ID is used and the Addr parameter is ignored. This mode is sometimes referred to as "pass-through" mode.

5.2 Modbus Floating Point Register (MFPREG)



The Modbus Floating Point Register point provides an interface to Modbus compatible slave devices. When used with an MSCAN point, the MFPREG connects to up to four blocks of floating point data, allowing access to a total of 64 register values.

5.2.1 Parameters

The database parameters used by the MFPREG point are listed and described below:

Configuration Parameters	Function
Tag	A Tag can contain 15 bytes of data and can include any printable ASCII character. Tags can be used to identify points indicating the use of the point such as "Modbus Slave" or "Register Value1." The default tag is set to "MFPREG.00"
Module	Not used.
Chan	Physical channel number the slave device is connected to. On the 8203 Dual RS-485 Communications Interface Module, the Chan can be set to 1 or 2. On the 8303 TGI motherboard, the Chan can be set to 0, 1 or 2.
BaudRate	Baud Rate for communications to the Slave device. Valid values are: 1200, 2400, 2400, 9600 and 19200. The BaudRate is set prior to scanning the device
ComParams	Defines the number of data bits and the parity used by the com port. Valid values include: 8N – 8 data bits, No parity 8O – 8 data bits, Odd parity 8E – 8 data bits, Even parity 7O – 7 data bits, Odd parity 7E – 7 data bits, Even parity The default is '8N'.
ID	Slave Address of the device to be scanned.
Mode	HEX byte value for the Operational Mode: 0x01 – Swap mode
ReadCmd	Command to use to Read data from the slave device
WriteCmd	Command to use to Write data to the slave device
Addr1 Size1 Addr2 Size2 Addr3 Size3 Addr4 Size4	Data Address and Block Size pairs. The MFPREG point will read data from the slave device, starting at Addr1 and request Size1 registers. Up to four blocks may be defined. If the Size is zero, then no read operation is performed. The data is returned to the Value array.

Configuration Parameters	Function
Report	Causes automatic notification to the Host (in response to a Change of State Request) when the Value Changes State. Parameter value can be High, Low or No. No disables notification. Points with Report = High will be sent before points with Report = Low. The default is High.
Maxtime	Specifies the maximum time (in secs) between automatic Change of State data being sent to the Host in response to a Change of State Request. Report must be set to either Low or High for the Value parameter to be sent in response to a Change of State Request. A value of 0 disables this option. Non-zero values cause responses to be sent even if the value has not changed since the last message. The maximum is 65535 seconds. The default is 600.

Dynamic Parameters	Function
Value0 Value63	Register values from slave device. Value0 will always correspond to the first register read from the slave device using the Addr1 and Size1 parameters. You can read up to 64 registers from the slave device. The meaning of the Value array depends upon the definition of the blocks.
PntStatus	Byte value indicating status of point Values are: 0x0000: No Error 0x0001: No Response from Device
Elapse	Time of the last request from the master
PntChecksum	CRC-16 Checksum of point's static Configuration Parameters

5.2.2 Application

The MFPREG point continually scans Modbus slave devices, using the ID parameter. Chan determines which 8203 Dual RS-485 Communications Interface Module Channel is used for communications to the slave device. An MFPREG point is needed for each device connected to the 8303 TGI. Up to 64 registers may be read with each MFPREG point. Multiple MFPREG points can be used with a single slave device if necessary. The BaudRate and ComParams values must match the communications parameters of the slave device. The communications parameters are set as each MFPREG point is processed. This allows slaves with different baud rates and data link settings to exist on the same bus (not recommended).

8203 TGI software points may begin scanning when the point is created, or when the correct Channel number is assigned. Which of these events begins the scanning process varies with each point.

A total of four blocks may be read or written. The ReadCmd determines the command to read data and the WriteCmd is the command used for write operations. The Addr and Size parameters determine the addresses. Set the Addr1 and Size1 parameters to read a data block from the slave device. The response will be placed in the Value0 – Value63 parameters. For example, if Addr1 = 100 and Size1 = 10, then the MFPREG point will read 10 register values and place the data in Value0 – Value9. If a second block is defined, then the data response will start in Value10. If the Size is 0, then that block is disabled.

The Mode parameter can be used to swap the byte order of the floating point values.

5.3 Modbus Scanner (MSCAN)



The Modbus Scanner point provides communication between the 8303 TGI and Modbus compatible slave devices represented by MG5000, MIREG, MFPREG, or any other Modbus slave interface points. It includes parameters for configuring that communication, and It provides dynamic and statistical information related to connected devices. Two MSCAN points (one for each channel) are automatically created when the motherboard detects the Model 8203.

5.3.1 Parameters

The database parameters used by the MSCAN point are listed and described below:

Configuration Parameters	Function
Module	Not used.
Chan	The physical channel (J2 or J4) used on the Model 8203. One MSCAN point is created automatically for each channel by the system. The Chan parameter is set in each MSCAN point and should not be changed. For more information about the Model 8203 COM channels, see section 2.2.3 on page 10.
MaxRetry	Value between 1–10 indicating the number of times the scanner will retry a request to a slave device. Default is 2.
Timeout	Time (in milliseconds) that a Device must respond to a request. Default is 2000.
ScanDelay	Time in milliseconds for the delay between scans. The default is 500.
BaudRate	Baud Rate for communications to the slave device. Valid values are: 1200, 2400, 4800, 9600 and 19200.
LevelConvert	Determines the units in which the level data will be displayed. F: Feet M: Meters Default is F.
TempConvert	Determines the units in which the temperature data will be displayed. F: Fahrenheit C: Celsius If no value is specified, no conversion will be performed. The default is F.
DensityConvert	Determines the units in which the density data will be displayed. A: API L: lbs/cu ft K: kgs/m3. If no value is specified, no conversion will be performed. The default setting for this point is A.

Dynamic Parameters	Function
ScanCmd	Allows the user to Enable, Disable, or Reset Scanning.
ID	Address of slave device.
Cmd	Current command. Values include: 1 – Read Output Status 2 – Read Input Status 3 – Read Output Registers 4 – Read Input Registers 5 – Force Single Coil 6 – Preset Single Register 15 – Force Multiple Coils 16 – Preset Multiple Registers
Pnt	Point currently being scanned. Examples include the MG5000, MIREG or MFPREG points.
NumRequests	Number of scan requests since the last reset
NumTrans	Number of completed transactions
NumComErrors	Number of requests with communications or context errors.
NumTimeouts	Number of requests that did not receive a response.
NumScanList	Number of devices in the Scan List
PntChecksum	CRC-16 Checksum of point's static Configuration Parameters

5.3.2 Application

The MSCAN point provides status information for the communications with any Modbus devices used with the 8303 TGI or the 8212 TRL/2. For the Model 8203, two MSCAN points are created at initialization when the motherboard detects the Model 8203. The point number created for each MSCAN point will correspond to the following table (the Module number is 1):

Channel	Point Number
Chan 1	MSCAN.01
Chan 2	MSCAN.02

Note The 8212 TRL/2 only has ONE MSCAN. Chan 1 is MSCAN.01.

Use the Upload command from the Config Menu to retrieve the data from the MSCAN point or any other points created automatically by the 8303 TGI.

The MSCAN point acts as a Modbus Master Protocol Handler (MSCAN) and works in conjunction with MIREG, MFPREG, MG5000, and other Modbus slave points. The Modbus Master Protocol Handler (MSCAN) sequentially processes these points, issuing data requests according to the ID, Addr and Size parameters. The MSCAN point provides dynamic information regarding the current request and total number of requests and errors.

The Chan parameters of the Modbus slave interface points must correspond with the Chan parameters of the applicable MSCAN point. For example, assume that switch SW1 on the Model 8203 is set to address 1. If a MTS MTG gauge is physically connected to terminal connector J2 (COM Channel A) on the Model 8203, the MG5000 point for that gauge must be set to Chan 1.

The NumRequests parameter gives the total number of requests attempted, while the NumTrans gives the number of completed transactions. The ID represent the current device address being scanned. The Pnt parameter is the Tag of the point being scanned.

5.4 Rosemount RAPTOR RTG (RAPTOR)



The Rosemount RAPTOR RTG (RAPTOR) Radar Gauge point provides an interface to Rosemount RAPTOR Radar Gauges. The RAPTOR point interfaces to Saab 3900 Series RAPTORs using Modbus. If communicating directly to the gauge, the RAPTOR point executes on the Model 8212 Saab TRL/2 Interface. The RAPTOR point can also be used with a Saab FCU.

5.4.1 Parameters

The database parameters used by the RAPTOR point are listed and described below:

Config Parameters	Function
Tag	A Tag can contain 15 bytes of data and can include any printable ASCII character. Tags can be used to identify the name of the tank being monitored. The default tag is set to "RAPTOR.00".
Description	The point description can contain 30 bytes of data and can include any printable ASCII character. Descriptions can be used as information relevant to any aspect of the point, such as its use, location, operating information, etc. The default description is set to "RAPTOR.00".
WMSeal	Coded Value that enables Weights & Measures password protection
Module	Not used.
Chan	Communications channel to which the gauge is connected. For an 8312, Chan is either 1 or 2.
ID	Physical Address of the tank gauge transmitter (0-999).
Addr	FCU Address (if Mode = 0x02)
LevelUnits	Specifies the engineering units for the level data read from the REX. m or M: levels in 1/10th millimeter s or S: levels in 1/16th inch The LevelUnits needs to match the units specified during the gauge setup. The Level can be converted from Metric to English (or vice-versa) by setting the LevelConvert parameter. Default is m.
LevelConvert	Determines the units in which the level data will be displayed. f: feet m: millimeters Default is m. If no value is specified, no conversion will be performed. Note the LevelUnits must be set properly. If the LevelUnits and the LevelConvert are the same, no conversion is performed.
TempUnits	Specifies the engineering units for the temperature data read from the REX. F: Fahrenheit C: Celsius The TempUnits needs to match the units specified during the gauge setup. The Temp can be converted from Metric to English (or vice-versa) by setting the TempConvert parameter. The default is C.

Config Parameters	Function
TempConvert	Determines the units in which the temperature data will be displayed. F: Fahrenheit C: Celsius If no value is specified, no conversion will be performed. The default is C.
AI1LowRange	Analog Input #1 Low Range.
AI1HighRange	Analog Input #1 High Range
AI2LowRange	Analog Input #2 Low Range.
AI2HighRange	Analog Input #2 High Range
ValueMin	Minimum Analog Input Integer Value
ValueMax	Maximum Analog Input Integer Value
LevelDeadband	Specifies the amount of change in the Level that must occur for the level to be updated each Change of State period. The default is 0.
Mode	Parameter used to control the operation of the REX point. 0x02: Communication via FCU
TempInterleave	Temperature Interleave Factor determines how often the temperature is read. The default is 10, which means that with every tenth scan of the REX, the temperature is read.
BaudRate	Baud Rate for communications to the Slave device. Valid values are: 1200, 2400, 4800, and 9600. The default is 4800.
ComParams	Defines the number of data bits and the parity used by the com port. Valid values include: 8N – 8 data bits, No parity 8O – 8 data bites, Odd parity 8E – 8 data bits, Even parity 7O – 7 data bits, Odd parity 7E – 7 data bits, Even parity The default is 8N.
Report	Causes automatic notification to the Host (in response to a Change of State Request) when the value changes state. Parameter value can be High, Low or No. Report=No disables automatic notification. Points with Report = High will be sent before points with Report = Low. The default is High.
MaxTime	Specifies the maximum time (in secs) between automatic Change of State responses being sent to the Host. Report must be set to either Low or High for the Value parameter to be sent in response to a Change of State Request. A value of 0 disables this option. Non-zero values cause responses to be sent even if the value has not changed since the last message. The maximum is 65535 seconds. The default is 600.
Watchdog	Enables the watchdog task on the Motherboard. The watchdog task monitors the REX point on the Model 8212 and verifies it is scanning gauges. If the Model 8212 fails, the 0x4000 and the 0x0001 bits of the PntStatus will be set to indicate the failure.

Dynamic Parameters	Function
Level	IEEE Floating point value representing the tank level. The data is returned in the format specified during the configuration of the gauge.
GaugeStatus	<p>Integer value indicating status of the gauge (Integer Register 6). Values are:</p> <p>0x0001: Hart Input 1 error 0x0002: Hart Input 2 error 0x0004: Hart Input 3 error 0x0008: Not Used 0x0010: Analog Input 1 Error 0x0020: Analog Input 2 Error 0x0040: Analog Input 2 Error 0x0080: RTG Communications Failure 0x0100: LPG verify copy 0x0200: Not Used 0x0400: Not Used 0x0800: Presentation level = M.I.P. level 0x1000: NMI-approved RTG 0x2000: NMI legal level (#-inverted). Not NMI = 0. 0x4000: Master, FCU set to 1 if REX does not answer 0x8000: Valid level</p>
Rate	Level Rate.
TankLevel	Value read from gauge.
Ullage	Ullage.
Analog1 through Analog3	Analog Currents (1, 2, and 3).
Temp1 through Temp6	Floating point value representing the product temperature at various levels. The data is returned in the format specified during the configuration of the gauge. Temp1–Temp6 can be converted from Metric to English (or vice-versa) by setting the TempConvert parameter.
TempFilter	16-Bit Status Code that determines if a temperature element is in liquid. (Register 19). For example, Bit 0 = 1 means Temp 1 is in liquid. For further explanation, see the REX documentation.
TempStatus	16-Bit Code that determines the Blocked status of the temperature elements. Register 1A). For example, Bit 0 = 1, means Temp 1 is Blocked. For further explanation, see the REX documentation.
TempDiagCode	16-Bit Error Code that determines the status of the temperature elements. Register 1B). For example, Bit 0 = 1, means Temp 1 is in Error. For further explanation, see the REX documentation.
Temp	Floating point value representing the average temperature of the product. The data is returned in the format specified during the configuration of the gauge.

Dynamic Parameters	Function
PntStatus	Byte value indicating status of point. Values are: 0x0001: No Response from device 0x0002: Device Error (Reg2 Bit7) 0x0004: Device Warning (Reg2 Bit1) 0x0008: 0x0010: No Response from RTG or DAU (when using FCU for Comm) 0x0020: Invalid Level (Reg2 Bit15 – Inverse) 0x0040: Invalid Avg Temperature (Register27 Bit15) – Not Supported in the RTG 0x0080: 0x0100: Analog1 Error (Reg2 Bit4 or Reg29 Bit0) 0x0200: Analog2 Error (Reg2 Bit5 or Reg29 Bit2) 0x0400: Hart Slave1 Error (Reg2 Bit6 or Reg42 Bit0) – Not Supported in the RTG 0x1000: W&M Seal is Enabled 0x2000: 0x4000: Module Failure 0x8000:
Elapse	Time of the last scan
PntChecksum	CRC–16 Checksum for point's static Configuration Parameters.
WMChecksum	Weights and Measures Checksum. This parameter is calculated when the WMSeal parameter is set to enable.

The RAPTOR point provides an interface to Rosemont Radar Tank Gauges (RAPTOR) using the TRL/2 bus using the Model 8212 TRL/2 Interface.

Model 8212 TRL/2 Interface

The Model 8212 provides the means to connect directly to the TRL/2 bus. The Model 8212 is automatically detected at start up, and an MSCAN point is automatically created to manage the scanning task.

The user only has to set the Chan, BaudRate, ComParams, and ID parameters in order to establish communications with the RAPTOR. The Chan determines which Channel is used for communications to the slave device. The Chan parameter must match the channel used to communicate with the RAPTOR.

The RAPTOR point can also be used to communicate with the Rosemont FCU (Field Communication Unit) by setting the mode parameter to 0x02 and setting the Addr parameters.

Weights & Measures Protection

The RAPTOR point can be sealed when used in a Weights & Measures application. Only certain parameters can be sealed.

These parameters will be shown in blue (CONSTANT parameters) when unlocked and will be grayed out when locked. To seal the point, set the WMSeal to Enable. Note that FuelsManager must be active in order to seal or unseal a point.

5.5 SAAB REX Radar (REX)



The The Saab REX Radar Gauge point provides an interface to Saab REX Radar Gauges. The REX point interfaces to Saab 3900 Series REXs using Modbus. If communicating directly to the gauge, the REX point executes on the 8212 Saab TRL/2 Interface. The REX point can also be used with a Saab FCU. The 8203 Dual RS-485 Interface Module can be used to read tank data from the Saab FCU.

5.5.1 Parameters

The database parameters used by the REX point are listed and described below:

Config Parameters	Function
Tag	A Tag can contain 15 bytes of data and can include any printable ASCII character. Tags can be used to identify the name of the tank being monitored. The default tag is set to "REX.00".
Description	The point description can contain 30 bytes of data and can include any printable ASCII character. Descriptions can be used as information relevant to any aspect of the point, such as its use, location, operating information, etc. The default description is set to "REX.00".
WMSeal	Coded Value that enables Weights & Measures password protection.
Module	Not used.
Chan	Communications channel to which the gauge is connected. For an 8203 Dual RS-485 Communications Interface Module Chan is either 1 or 2.
ID	Physical Address of the tank gauge transmitter (0-999).
Addr	FCU Address (if Mode = 0x02)
LevelUnits	Specifies the engineering units for the level data. s: sixteenths m: millimeters The LevelUnits needs to match the units specified during the gauge setup. Default is m.
LevelConvert	Determines the units in which the level data will be displayed. F: Feet m: millimeters Default is m.
TempUnits	Specifies the engineering units for the temperature data. F: Fahrenheit C: Celsius The TempUnits needs to match the units specified during the gauge setup. The Temp can be converted from Metric to English (or vice-versa) by setting the TempConvert parameter in the appropriate MSCAN or RKSCN point.
TempConvert	Determines the units in which the temperature data will be displayed. F: Fahrenheit C: Celsius If no value is specified, no conversion will be performed. The default is C.

Config Parameters	Function
AI1LowRange	Analog Input #1 Low Range.
AI1HighRange	Analog Input #1 High Range
AI2LowRange	Analog Input #2 Low Range.
AI2HighRange	Analog Input #2 High Range
AI3LowRange	Analog Input #3 Low Range.
AI3HighRange	Analog Input #3 High Range
ValueMin	Minimum Analog Input Integer Value
ValueMax	Maximum Analog Input Integer Value
LevelDeadband	The LevelDeadband sets the deadband for the Change of State mode. The default is 0.1.
Mode	Parameter used to control the operation of the AT4530 point. 0x100 – AT4530 is connected to a SG6000 (Not a TM4590)
Temperature	Floating point value representing the product temperature. The data is returned in the format specified during the configuration of the gauge.
BaudRate	8203 Dual RS-485 Communications Interface Module: Valid values are: 4800. The default is 4800.
ComParams	Defines the number of data bits and the parity used by the com port. Valid values include: 8N – 8 data bits, No parity 8O – 8 data bits, Odd parity 8E – 8 data bits, Even parity 7O – 7 data bits, Odd parity 7E – 7 data bits, Even parity The default is 8N.
Report	Causes automatic notification to the Host (in response to a Change of State Request) when the Level, Temp, Position changes. Parameter value can be High, Low or No. Report=No disables automatic notification. Points with Report = High will be sent before points with Report = Low. The default is High.
MaxTime	Specifies the maximum time (in secs) between automatic Change of State responses being sent to the Host. Report must be set to either Low or High for the Value parameter to be sent in response to a Change of State Request. A value of 0 disables this option. Non-zero values cause responses to be sent even if the value has not changed since the last message. The maximum is 65535 seconds. The default is 600.
Watchdog	Enables the watchdog task on the Motherboard. The watchdog task monitors the MBMFT point on the 8203 Dual RS-485 Communications Interface Module and verifies it is scanning for gauges. If the 8203 Dual RS-485 Communications Interface Module fails, the 0x0010 and the 0x0001 bits of the PntStatus will be set to indicate the failure.

Dynamic Parameters	Function
Level	IEEE Floating point value representing the tank level. The data is returned in the format specified during the configuration of the gauge.
GaugeStatus	Integer value indicating status of the gauge (Integer Register 6). Values are: 0x0001: Bad Level 0x0002: Bad Temp 0x0004: Bad EE 0x0008: Bad EE Checksum 0x0010: Bad RAM 0x0020: Bad EEPROM 0x0040: Local Modifications 0x0080: No Calculation 0x0100: CFG Error 0x0200: Calc Error 0x0400: Bad CPU Board 0x0800: Bad Comm Board 0x1000: Low Encoder Battery
Rate	Level Rate.
TankLevel	Tank Level.
Ullage	Measured Distance. Distance from radar to product.
Analog1 through Analog3	4 to 20 mA value %
Temp1 through Temp5	Floating point value representing the product temperature at various levels. The data is returned in the format specified during the configuration of the gauge. Temp1–Temp16 can be converted from Metric to English (or vice-versa) by setting the TempConvert parameter of the appropriate MSCAN or RKSCN point.
TempFilter	Temp in Liquid parameter. Bits 0 – 13 indicate if Temp sensors 1 – 14 are submerged in liquid. Bit 14 indicates a System Error. Bit 15 indicates a Temp calibration error. 0x0001: Temp 1 is in Liquid 0x0002: Temp 2 is in Liquid 0x0004: Temp 3 is in Liquid 0x0008: Temp 4 is in Liquid 0x0010: Temp 5 is in Liquid 0x0020: Temp 6 is in Liquid 0x0040: Temp 7 is in Liquid 0x0080: Temp 8 is in Liquid 0x0100: Temp 9 is in Liquid 0x0200: Temp 10 is in Liquid 0x0400: Temp 11 is in Liquid 0x0800: Temp 12 is in Liquid 0x1000: Temp 13 is in Liquid 0x2000: Temp 14 is in Liquid 0x4000: System Error 0x8000: Temp Calibration error

Dynamic Parameters	Function
TempStatus	<p>Temp status parameter (blocked). This parameter indicates the blocked status of each temperature sensor.</p> <p>0x0001: Temp 1 blocked 0x0002: Temp 2 blocked 0x0004: Temp 3 blocked 0x0008: Temp 4 blocked 0x0010: Temp 5 blocked 0x0020: Temp 6 blocked 0x0040: Temp 7 blocked 0x0080: Temp 8 blocked 0x0100: Temp 9 blocked 0x0200: Temp 10 blocked 0x0400: Temp 11 blocked 0x0800: Temp 12 blocked 0x1000: Temp 13 blocked 0x2000: Temp 14 blocked 0x4000: Legal NMI-temperature 0x8000: NMI approved DAU</p>
TempDiagCode	<p>Temp diagnostic code parameter. This parameter indicates the error status of each temperature sensor.</p> <p>0x0001: Temp 1 error 0x0002: Temp 2 error 0x0004: Temp 3 error 0x0008: Temp 4 error 0x0010: Temp 5 error 0x0020: Temp 6 error 0x0040: Temp 7 error 0x0080: Temp 8 error 0x0100: Temp 9 error 0x0200: Temp 10 error 0x0400: Temp 11 error 0x0800: Temp 12 error 0x1000: Temp 13 error 0x2000: Temp 14 error 0x4000: Master (set if using an FCU and DAU does not respond) 0x8000: Temp average error. No temperature sensor is in liquid.</p>
Temp	<p>Floating point value representing the average product temperature. The data is returned in the format specified during the configuration of the gauge.</p>
EIapse	<p>Time of the last scan</p>

Dynamic Parameters	Function
PntStatus	Byte value indicating status of point. Values are: 0x0000: No error 0x0001: Gauge Not Responding 0x0010: FCU is offline (if Mode = 0x02) 0x1000: Weights & Measure Seal is Enabled 0x4000: Failure of the Model 8212. This bit is set if the Watchdog task on the Motherboard determines that the Model 8212 has stopped updating.
PntChecksum	CRC-16 Checksum for point's static Configuration Parameters.
WMChecksum	Weights and Measures Checksum. This parameter is calculated when the WMSeal parameter is set to enable.

5.5.2 Application

The REX point provides an interface to Saab Radar Tank Gauges (REX) using two methods:

- Directly to the TRL/2 bus using a Model 8212
- Via an FCU, using a Model 8203 (MODx_xx firmware)

Model 8212 TRL/2 Interface

The Model 8212 provides the means to connect directly to the TRL/2 bus. The Model 8212 is automatically detected at startup, and an MSCAN point is automatically created to manage the scanning task. The Module and Chan determine which Module and Channel are used for communications to the slave device. Module = 1 corresponds to the Model 8212 set to address 1, Module = 2 corresponds to the Model 8212 set to address 2, etc. The Chan parameter must match the channel used to communicate with the Saab REX.

Model 8203 Dual RS-485 Interface

If the REX Gauges are connected to a Saab FCU, then a Model 8203 is used to read data, The Model 8203 is automatically detected at startup, and an MSCAN point is automatically created to manage the scanning task. The Module and Chan determine which Module and Channel are used for communications to the slave device. Module = 1 corresponds to the Model 8203 set to address 1, Module = 2 corresponds to the Model 8203 set to address 2, etc. The Chan parameter must match the channel used to communicate with the Saab REX.

An REX point is needed for each device connected to the 8130 RTU. The ID must match the unit address of the Saab REX. Scanning begins when the Module is assigned. The BaudRate and ComParams values must match the communications parameters of the Radar Tank Gauge. The communications parameters are set as each REX point is processed.

The REX point works in conjunction with the Modbus Master protocol handler. MSCAN points are automatically created and the user only has to set the Module, Chan, BaudRate, ComParams and ID parameters in order to establish communications with the Saab REX.

The Mode parameter determines whether the REX point reads the data from the Saab FCU's holding registers. If the Mode is 0x02, then the data is read from the holding registers. The Addr parameter determines the FCU address and the ID is not used. If the Mode is 0, then the FCU sends the request to the REX and sends the response back to the 8130 RTU. The ID is used and the Addr parameter is ignored. This mode is sometimes referred to as "pass-through" mode.

Weights & Measures Protection

The REX point can be sealed when used in a Weights & Measures application. Only certain parameters can be sealed. These parameters will be shown in blue (CONSTANT parameters) when unlocked and will be greyed out when locked. To seal the point, set the WMSeal to Enable. Note that FuelsManager must be active in order to seal or unseal a point.

5.6 Saab Radar Tank Gauge (RTG)



The Saab Radar Tank Gauge point provides an interface to Saab Radar Tank Gauges. The RTG point interfaces to Saab 2920, 2930, 2940, 2960, 3920, 3930, 3940 and 3960 RTGs using Modbus. The RTG point executes on the 8312 Saab (TRL/2) Interface Module. The RTG point can also be used with a Saab FCU. The 8203 Dual RS-485 Interface Module can be used to read tank data from the Saab FCU.

5.6.1 Parameters

The database parameters used by the RTG point are listed and described below:

Configuration Parameters	Function
Tag	A Tag can contain 15 bytes of data and can include any printable ASCII character. Tags can be used to identify the name of the tank being monitored. The default tag is set to "RTG.00".
Description	The point description can contain 30 bytes of data and can include any printable ASCII character. Descriptions can be used as information relevant to any aspect of the point, such as its use, location, operating information, etc. The default description is set to "RTG.00".
WMSeal	Coded value that enables Weights & Measures password protection.
Module	Not used.
Chan	Physical channel number the RTG is connected to. On the 8312 Saab (TRL/2) Interface Module or 8303 Dual RS-485 Communications Interface Module, the Chan can be set to 1 or 2.
ID	Physical Address of the tank gauge transmitter (0-999).
Addr	FCU Address (if Mode = 0x02)
LevelConvert	Convert Level to standard F: Feet M: Meters m: millimeters. Default is millimeter.
LevelDeadband	The LevelDeadband sets the deadband for the Change of State mode. The default is 0.1.
AI1LowRange	Analog Input #1 Low Range.
AI1HighRange	Analog Input #1 High Range
AI2LowRange	Analog Input #2 Low Range.
AI2HighRange	Analog Input #2 High Range
AI3LowRange	Analog Input #3 Low Range.
AI3HighRange	Analog Input #3 High Range
ValueMin	Minimum Analog Input Integer Value
ValueMax	Maximum Analog Input Integer Value

Configuration Parameters	Function
LevelUnits	Specifies the engineering units for the level data. F: feet, m: Millimeters, s: sixteenths of inches. The LevelUnits needs to match the units specified during the gauge setup. The Level can be converted from Metric to English (or vice-versa) by setting the LevelConvert parameter .
Mode	Parameter used to control the operation of the TM4590 point. It has different meanings, depending on whether the 8303 Dual RS-485 Communications Interface Module is used. 8303 Dual RS-485 Communications Interface Module: 0x0010: Use old NMS operational status codes 8211 Current Loop (Whessoe Bus) Interface Module: Mode 0: Task 1, Task 36, Task 17, Task 30 Mode 0x01: Task 1 only Mode 0x02: Task 36 only Mode 0x04: Task 17 only Mode 0x08: Task 30 only
BaudRate	Baud Rate for communications to the Slave device. 8203 Dual RS-485 Communications Interface Module: Valid values are: 4800 The default is 4800. 8211 Current Loop (Whessoe Bus) Interface Module: Valid values are: 1200, 2400.
ComParams	Defines the number of data bits and the parity used by the com port. Valid values include: 8N – 8 data bits, No parity 8O – 8 data bits, Odd parity 8E – 8 data bits, Even parity 7O – 7 data bits, Odd parity 7E – 7 data bits, Even parity The default is 8N.
Report	Causes automatic notification to the Host (in response to a Change of State Request) when the Level, Temp, Position changes. Parameter value can be High, Low or No. Report=No disables automatic notification. Points with Report = High will be sent before points with Report = Low. The default is High.
MaxTime	Specifies the maximum time (in secs) between automatic Change of State responses being sent to the Host. Report must be set to either Low or High for the Value parameter to be sent in response to a Change of State Request. A value of 0 disables this option. Non-zero values cause responses to be sent even if the value has not changed since the last message. The maximum is 65535 seconds. The default is 600.
Watchdog	Enables the watchdog task on the Motherboard. The watchdog task monitors the MBMFT point on the 8203 Dual RS-485 Communications Interface Module and verifies it is scanning for gauges. If the 8203 Dual RS-485 Communications Interface Module fails, the 0x0010 and the 0x0001 bits of the PntStatus will be set to indicate the failure.

Dynamic Parameters	Function
Level	IEEE Floating point value representing the tank level. The data is returned in the format specified during the configuration of the gauge.
GaugeStatus	Integer value indicating status of the gauge (Integer Register 6). Values are: 0x0001: Bad Level 0x0002: Bad Temp 0x0004: Bad EE 0x0008: Bad EE Checksum 0x0010: Bad RAM 0x0020: Bad EEPROM 0x0040: Local Modifications 0x0080: No Calculation 0x0100: CFG Error 0x0200: Calc Error 0x0400: Bad CPU Board 0x0800: Bad Comm Board 0x1000: Low Encoder Battery
Rate	Level Rate
TankLevel	Tank Level
Ullage	Ullage
Analog1	Analog Current 1
Analog2	Analog Current 2
Analog3	Analog Current 3
PntStatus	Byte value indicating status of point. Values are: 0x0000: No error 0x0001: Gauge Not Responding 0x0010: FCU is offline (if Mode =0x02) 0x1000: Weights & Measure Seal is Enabled 0x4000: Failure of the 8312 Saab (TRL/2) Interface Module . This bit is set if the Watchdog task on the Motherboard determines that the 8312 Saab (TRL/2) Interface Module has stopped updating.
Elapse	Time of the last scan
WMCheckSum	Weights and Measures Checksum. This parameter is calculated when the WMSeal parameter is set to enable.
PntCheckSum	CRC-16 Checksum for point's static Configuration Parameters

5.6.2 Application

The RTG point provides an interface to Saab Radar Tank Gauges (RTG) using two methods:

- Directly to the TRL/2 bus using a 8312 Saab (TRL/2) Interface Module
- Via an FCU, using a 8303 Dual RS-485 Communications Interface Module (MDTGx_xx firmware)

8312 Saab (TRL/2) Interface Module

The 8312 Saab (TRL/2) Interface Module provides the means to connect directly to the TRL/2 bus. The 8212 Saab (TRL/2) Interface Module is automatically detected at startup, and an MSCAN point is automatically created to manage the scanning task. Chan determines which Channel is used for communications to the slave device. The Chan parameter must match the channel used to communicate with the Saab RTG.

8303 Dual RS-485 Communications Interface Module

If the Radar Tank Gauges are connected to a Saab FCU, then a 8303 Dual RS-485 Communications Interface Module is used to read data. The 8303 Dual RS-485 Communications Interface Module is automatically detected at startup, and an MSCAN point is automatically created to manage the scanning task. Chan determines which Channel is used for communications to the slave device. The Chan parameter must match the channel used to communicate with the Saab RTG.

8303 TGI software points may begin scanning when the point is created, or when the correct Channel number is assigned. Which of these events begins the scanning process varies with each point.

An RTG point is needed for each device connected to the 8303 TGI. The ID must match the unit address of the Saab RTG. The BaudRate and ComParams values must match the communications parameters of the Radar Tank Gauge. The communications parameters are set as each RTG point is processed.

The RTG point works in conjunction with the Modbus Master Protocol Handler (MSCAN). MSCAN points are automatically created and you only have to set the Chan, BaudRate, ComParams and ID parameters in order to establish communications with the Saab RTG.

The Mode parameter determines whether the RTG point reads the data from the Saab FCU's holding registers. If the Mode is 0x02, then the data is read from the holding registers. The Addr parameter determines the FCU address and the ID is not used. If the Mode is 0, then the FCU sends the request to the RTG and sends the response back to the 8303 TGI. The ID is used and the Addr parameter is ignored. This mode is sometimes referred to as "pass-through" mode.

Weights & Measures Protection

The RTG point can be sealed when used in a Weights & Measures application. Only certain parameters can be sealed. These parameters will be shown in blue (CONSTANT parameters) when unlocked and will be grayed out when locked. To seal the point, set the WMSeal to Enable. Note that FuelsManager must be active in order to seal or unseal a point.

6 Installation

Before attempting installation, review the Safety Precautions below. Installation and maintenance personnel should become familiar with any hazards present as well as any agency requirements before working with any equipment.

6.1 General Safety Guidelines

The user should follow safety guidelines provided by the Occupational Safety and Health Administration (OSHA) for additional protection. Information may be obtained from the following sources:

- National Electric Code (NEC)
- National Fire Protection Association (NFPA)
- Instrument Society of America (ISA)
- Factory Mutual Research Corporation (FM)
- Underwriters' Laboratories Incorporated (UL)
- Canadian Standards Association (CSA)

When in doubt about the safety of an area, the user should check with the local safety authorities. Always observe warning signs posted in the area and all labels on equipment.

6.2 Installation Safety Guidelines

- Never attempt to make voltage measurements within the Tank Gate Interface in the field.
- Maintenance should be performed only by authorized personnel.
- Always turn off the power before removing the case cover.
- Before installing/repairing any wiring to the Tank Gate Interface, make sure that the power is turned off at the main circuit breaker or switch. The power switch should be locked in the OFF position and labeled to prevent other personnel from turning the power on during installation.
- Before turning on power when installation is complete, make sure the cover of the Tank Gate Interface case is in place and tightly closed. NEVER REMOVE ANY COVERS WITHOUT FIRST TURNING OFF THE POWER.
- To prevent shock hazards, the housing of all units should be properly grounded in accordance with the National Electric Code. A grounding conductor should be wired to the grounding terminal provided on the Tank Gate Interface.
- In some applications, a substantial amount of heat is produced by other equipment inside or outside the enclosure. To assist in air circulation, place blower fans inside the enclosure.
- To prevent excessive heat, several steps can be taken. For most applications, normal convection cooling will keep the device components in the enclosure within the operating range. Proper spacing of components within the enclosure is usually sufficient for heat dissipation.
- Caution should be exercised when entering any area that is posted or otherwise assumed to contain hazardous gases. Always follow the guidelines provided by the Occupational Safety and Health Administration for your own protection.

Caution! Do not bring in unfiltered outside air. It may introduce harmful contaminants that could damage the Tank Gate Interface and components.

Caution! Never perform maintenance with power applied.

6.3 Installation

Standard systems are shipped with the motherboard and tank gauge interface module installed. The Tank Gate Interface installation procedure includes the installation of these individual components. Tank Gate Interface installation includes the following steps:

1. Mounting the Tank Gate Interface (section 6.3.1 on page 70)
2. Selecting the Unit Address (section 6.3.2 on page 70)
3. Wiring up Power (section 6.3.3 on page 70)
4. Grounding the Tank Gate Interface (section 6.3.4 on page 72)
5. Installing Communications (section 6.3.5 on page 72)


6.3.1 Mounting the Tank Gate Interface

Before mounting the Tank Gate Interface, make certain that any enclosure used can house the Tank Gate Interface. Refer to the dimensional drawing below (all dimensions are in inches). The recommended standard housing for the Tank Gate Interface is a NEMA TYPE 4 enclosure. This enclosure is suitable for both indoor and outdoor applications.

6.3.2 Select the Unit Address

Switch SW1 sets the Tank Gate Interface's one byte, binary address (0–15). Switch SW1–1 is the most significant bit (MSB) while switch SW1–4 is the least significant bit (LSB). When a switch is in the ON or CLOSED position, the resulting bit is a one.

Figure 6–1: Switch SW–1 setting for ID 1



6.3.3 Wiring Up Power

The Tank Gate Interface operates from AC power.

Wiring 120 or 220 VAC Power

The Tank Gate Interface is powered by an isolation transformer with a 5 volt regulator.

- Remove cover if it is in place
- Connect the two power leads to terminals L and N of connector J2.
- Ensure that a ground connection is connected to the G terminal ground of connector J2. (see below)
- Install cover.




Figure 6-2: Tank Gate Interface Dimensions

6.3.4 Grounding

To allow use in harsh industrial environments, the Tank Gate Interface incorporates ANSI/IEEE surge protection. In solid-state control systems, grounding helps limit the effects of noise due to electromagnetic interference (EMI) and provides additional surge protection when high voltage switching circuits are connected to the unit. The grounding path for the Tank Gate Interface and its enclosure is provided by the equipment grounding connector. The resistance from the Tank Gate Interface ground to the grounding electrode must not exceed 1 ohm. Additional ground wires should be connected as required for each I/O module.

Caution! All applicable codes and ordinances must be observed when wiring the Tank Gate Interface.

6.3.5 Installing Communications

6.3.5.1 RS-232 Communications

- To install the RS-232 communication option, connect an RS-232 cable to connector J7 (COM0).

Note The 8311 TGI only supports communication on COM0.

6.3.5.2 Power-Up

Before the field cables are attached, perform an initial system verification.

6.3.5.3 Initial system verification

- Connect the power cable to power connector P1, then connect an RS-232 cable from a PC with ViewRTU to J7 (COM0).
- Power up the unit.

The CPU LED on the tank gauge interface module should toggle on and off. If the CPU indicator is not flashing, turn off system power and proceed with the Troubleshooting and Calibration chapter.

6.3.5.4 Establishing Host Communications

When the main system power is turned on, the Host communications status is set to On-line by default. The Tank Gate Interface then waits for a valid poll from the Host computer. If the communication cable is installed and the Host is running, a communications link is established. Verify this condition with a hand-held terminal or ViewRTU.

6.3.5.5 Verifying Host Communications

- Display the COM Point and verify that an On-line condition is indicated.

7 Using ViewRTU

7.1 Overview

This chapter describes the software used to configure the Tank Gate Interface. This chapter describes each of the menus found in the menu bar. Additionally, the chapter describes the system requirements and the installation procedure. Use this chapter in accordance with the Tank Gate Interface Software Blocks section.

ViewRTU software, a Microsoft Windows application, is designed to configure and view data points in the Tank Gate Interface. ViewRTU is a utility program that can be used for configuration, diagnostics, data acquisition and control. Since ViewRTU follows the Windows standard, the user that is familiar with Windows will be able to learn the program quickly. ViewRTU supports the Windows standard of selecting commands from a series of pull-down menus. If the user is not familiar with Windows-based programs, then refer to the Microsoft Windows manual for basic instruction.

7.2 System Requirements

The minimum requirements needed to run the ViewRTU application are listed below:

- 386/486/Pentium Personal Computer
- Microsoft Windows NT, 2000, or XP
- 96 MB RAM
- 2 MB free disk space
- 1 Com Port

7.3 Installing ViewRTU

To install the ViewRTU application, follow the steps listed below.

Installing ViewRTU

- Insert the CD into the CDROM or DVDROM drive.
- Select the drive that contains the disk from the Windows File Manager.
- Double click on the SETUP.EXE file. The setup program prompts the user for the drive and directory used to install the software.
- Select the drive and type in the directory name. Once the drive and directory are selected, the setup program copies all of the files to the chosen destination.
- When all of the files have been copied to the destination, the setup program automatically builds a program group with corresponding program items in the Windows Program Manager.

7.4 Executing ViewRTU



This section describes how to start up the ViewRTU program. The components of the window are also described in this section. To execute the ViewRTU program, follow the steps below:

Execute the ViewRTU program,

1. Select the ViewRTU program group from the Windows Program Manager.
2. Double-click on the icon to execute the ViewRTU application.

If more than one Tank Gate Interface definition file (DVR) exists, the following dialog box is displayed.




Figure 7-1: ViewRTU Version Selection dialog

Each version file contains setup information that matches the firmware in the Tank Gate Interface. This information allows a single version of ViewRTU to configure multiple versions of the Tank Gate Interface. For example, MSTG1_00.DVR is a definition file that is compatible with Tank Gate Interface firmware version 1.00. Select the version that matches the version of firmware in the Tank Gate Interface. Note that you can determine the firmware version by viewing the SysVer parameter of the SYS point.

3. Choose the desired version and select OK.

If only one Tank Gate Interface definition file (DVR) exists, the main window appears instead. The main window is seen below.

When the ViewRTU program is opened, a new file appears in the window. The components of this window are explained below.




Figure 7-2: Main ViewRTU window with descriptions

7.4.1 ViewRTU window

This main window allows the user to perform the commands necessary to configure the Tank Gate Interface. The ViewRTU window contains the standard Windows components such as the Application Control menu, minimize/maximize icon buttons, title bar and menu bar.

The System Status area

Displays the system version as well as general information about the configuration file. The Tank Gate Interface file name is found in both the System Status area and the title bar.

The Tabular

Contains several push-button icons used to execute frequently used commands found in the menu bar. In the menu description below, each appears next to its associated menu option.

The Spreadsheet summary

Lists all the point types and corresponding number defined in the file. The Spreadsheet Mode can be used as a quick method for creating and editing the contents of each point by double-clicking on the desired point type. The parameters listed in the Spreadsheet summary directly correlate with each defined point.

Point Icon Selection Area

All the point icons are displayed in the Point Icon Selection Area. Point icons are visual representations of various software functions. When a new file is opened, several default point icons are displayed in the Point Icon Selection Area. These points are described in the Tank Gate Interface Software Blocks chapter.

7.5 The ViewRTU Menu Bar

This section describes all the menus found in the ViewRTU menu bar. The push-button icons found in the Toolbar are shown next to each associated menu option. This section primarily describes the functionality of each menu option. ViewRTU applications are presented in the Application section at the end of the chapter.

7.5.1 The File Menu

The File menu allows the user to create, open, and save configuration files. This menu also allows the user to save the current configuration to a different file name



Figure 7-3: The File menu

New



The user is able to create a new configuration file by clicking on the New push-button from the tool bar or by selecting New from the File menu. When selected, a dialog box appears displaying a list of configuration definition files. The user selects the desired file from this list.

Open



The user is able to select an existing configuration file by clicking on the Open push-button from the tool bar, or by selecting Open from the File menu. When selected, a dialog box appears displaying a list of configuration files. All configuration files are identified by the RCF extension. Once a file is selected, the point configuration data of the selected file is displayed. If the directory is empty, the user has the option of creating a new file by typing in the file name.

Save



The user is able to save the opened configuration file by clicking on the Save push-button from the tool bar or by selecting Save from the File menu. The user can save the file anytime the configuration has changed. If the file exists in the directory, the configuration is stored to the disk using the current file name. If the file has not been saved before or the name does not exist in the directory, the user is prompted to enter a configuration file name.

Save As

The Save As option is used to save the currently opened file under a different name. When selected, a dialog box appears prompting the user to enter a file name. If the selected file name already exists, the user has the option of overwriting the file. Otherwise, the user can create a separate file containing all the current configuration data of the present file. If the user chooses to create a separate file, the current file is automatically closed. Only one file may be open at a time.

Exit

The Exit option is used to close the ViewRTU application. If the current configuration file has not been saved, the user is prompted to save the file or cancel the option.

7.5.2 The Point Menu




Figure 7-4: The Point Menu

Add



The user is able to add a point to the current configuration. The user is able to add a point by clicking on the Add Point push-button from the tool bar or by selecting Add from the Point menu. The Select Point to Add dialog box appears:




Figure 7-5: Dialog viewed when adding a new point

Select Point to Add dialog box

This dialog box displays a list of available point types, the point number, quantity and the corresponding point icon. The point icon is then added to the Point Icon Selection Area if it does not already exist. The Point Type lists the currently selected point. The user can select the desired point by selecting the point from the scroll list.

The Point Number defaults to “0” if the point type has just been defined. The maximum number of points entered depends on the selected point type. Once entered, the point quantity is displayed in the Summary Spreadsheet.

Multiple points of the selected type may be created simultaneously by entering the number in the Quantity edit box.

Edit



This option is used to modify the contents of a selected point. The user is able to edit an existing point by clicking on the Edit push-button from the toolbar or by selecting Edit Point from the Point menu. The Select Point to Edit dialog box appears:




Figure 7-6: Edit Point selection dialog

Edit Point selection dialog

This dialog box displays a list of defined point types and corresponding point numbers. The point icon is also displayed for identification as well as the tag, if a tag has been assigned.

Once a point is selected, the Edit Point dialog box appears:




Figure 7-7: Edit Point dialog

Edit Point dialog

This dialog box contains all dynamic and configurable field information. The user is able to edit point data. Exiting this dialog box returns the user to the main window.

Note Several other methods can be used to display the Edit Point dialog box. These methods and other information are explained in greater detail in the Application section.

Delete



This option lets the user delete one point at a time. The user is able to delete an existing point by clicking on the delete push-button from the toolbar or by selecting Delete Point from the Point menu. The Select Point to Delete dialog appears:




Figure 7-8: Point deletion dialog

Point deletion dialog

This dialog box displays a list of defined point types and corresponding point numbers. The point icon is also displayed for identification as well as the tag, if a tag has been assigned.

The user selects the point type and the corresponding number to be deleted.

7.5.3 The Config Menu




Figure 7-9: The Configuration Menu

Download Database to RTU

The Download Database to RTU option is used to download configuration data to the Tank Gate Interface. The following dialog box appears:




Figure 7-10: Dialog used to download Tank Gate Interface data

Click the Download push-button to download data to the Tank Gate Interface

Upload Database from Tank Gate Interface

The Upload option is used to upload configuration data from the Tank Gate Interface. The following dialog box appears:




Figure 7-11: Dialog used to upload Tank Gate Interface data

Click the Upload push-button to download data from the Tank Gate Interface. Once the upload is complete, the main window changes to display the uploaded configuration.

Spreadsheet

The Spreadsheet option is used to configure, download, and upload point data points in spreadsheet mode.




Figure 7-12: Spreadsheet Mode Edit window

Password

The user can use the Password option to gain access to a protected file.

Once a password has been assigned, the user must enter the password when attempting to edit the Tank Gate Interface configuration file. This password is only entered once in the duration of the ViewRTU program.

To enter the password

- Select Config and click on Password.
- Click on the edit box in the Password dialog. Type in the password.
- Click on OK.



Figure 7-13: Configuration Password dialog

Modify Password

The user can use the Modify Password function to protect all Tank Gauge Configuration files by issuing and changing a password.

Creating a Password

- Select Config and click on Password. The Change Password dialog appears.
- In the New Password edit box, enter the password. If no password currently exists, leave the Old Password field blank.
- In the Retype New Password edit box, confirm the entry by reentering the password.
- Click on OK.



Figure 7-14: Change Password dialog

Note Make sure that you write down the password and store it in a secure place.

Changing the Password

- Select Config and click on Modify Change Password. The Change Password dialog appears, as illustrated in 'creating a password'.
- In the Old Password edit box, enter the current password.
- In the New Password edit box, enter the new password.
- In the Retype New Password edit box, confirm the entry by reentering the new password.
- Click on OK.

Note Make sure that you write down the password and store it in a secure place.

7.5.4 The Communications Menu




Figure 7-15: The Communications Menu

PC Setup

The PC Setup option allows the user to define the communications channel and data rate characteristics of the communications port. When selected, the following dialog box appears. This example dialog box contains the default settings for communications setup.




Figure 7-16: Port Communications Setup dialog

Port Communications Setup dialog

This dialog box allows the user to enter the specifications of the Tank Gate Interface's communication port. When OK is selected, the setup data is stored as the default setup next time ViewRTU is executed.

Status

The Status option is provided so the user is able to observe communications data. The following dialog box appears when this option is selected.




Figure 7-17: Communications Diagnostics dialog

Connect

The Connect option is used when the user needs to search for a specific Tank Gate Interface. The following dialog box appears when the option is selected.




Figure 7-18: Tank Gate Interface search dialog

Tank Gate Interface search dialog

This dialog box lists the address, description and current status of each Tank Gate Interface. From this dialog box the user can select an Tank Gate Interface and establish communications with the selected Tank Gate Interface.

7.5.5 The Options Menu




Figure 7-19: The Options Menu

Convert Configuration Files

The Convert Configuration Files option is used once the Download Firmware option has been executed. This option converts configuration files from one version to another. When selected, the following dialog box appears.




Figure 7-20: Convert ViewRTU versions dialog

Convert ViewRTU versions dialog

This dialog box allows the user to convert a file. The user has the option of first analyzing the effects of converting the file. A script file can also be selected to alter the behavior of the conversion. Script files are provided on the upgrade disk.

Export All

The Export All option allows the user to export all of the database in the Tank Gate Interface. Each point type is exported to a file in the CSV file format. For example, the Analog Input points are all exported to the file 'AI.CSV'. This means that the user can not specify each file name as the data is exported. The user does have the ability to specify the directory to export the data to. The user must create and then select the subdirectory for the export operation. We suggest

that you organize the directories with names corresponding to the Tank Gate Interface address. If you have two Tank Gate Interface's, use the Windows File Manager program to create subdirectories \VIEWRTU\RTU1 and \VIEWRTU\RTU2. All of the files for Tank Gate Interface #1 should be written to \VIEWRTU\RTU1; Tank Gate Interface #2's data would go to \VIEWRTU\RTU2 and so on.

The exported data can be edited using a spreadsheet program such as Microsoft Excel, or a database program like Microsoft Access. Many programs can read and write data in the CSV file format. You can make backups of your RCF file by exporting the data in the CSV file format.

The exported data can be read back with the Import All option. The Spreadsheet Mode also has an option to import CSV file data.

Import All

The Import All option allows the user to import the entire Tank Gate Interface database. Each point type must have been exported previously in order to import data. This can be accomplished using the Export All option, or by point type using the Spreadsheet Mode. The data is read from files in the CSV file format. For example, all of the Analog Input points are imported from the file 'AI.CSV'. The user must select the subdirectory to import the data from.

The CSV file data can also be imported using the Spreadsheet mode.

View I/O List

The View I/O List option allows the user to create a list of the I/O points connected to the Tank Gate Interface. The list is limited by listing points that have the Chan or Module parameters. These parameters are always used in cases where I/O is involved. The list is created by writing to the file 'POINTLST.TXT' and launching the Notepad program. The user can print this file using Notepad, or exit and return to ViewRTU.

Set Time in RTU

The Set Time in RTU option sets the time in the CLK point to the same time as the PC running ViewRTU.

7.5.6 The Help Menu




Figure 7-21: The Help Menu

Contents

The Contents option opens the table of contents of the ViewRTU on-line help.

Index

The Index option opens the index for the ViewRTU on-line system. This index lists all the help screens contained in the help system.

About VRTU

The About RTU... option displays a dialog box describing the copyright information and the application version number.

7.6 Using ViewRTU

By using ViewRTU, the user is able to define or modify sub-programs called Software Blocks. Software blocks are used to configure the Tank Gate Interface.

Note Refer to the Tank Gate Interface Software Blocks chapter for specific examples. The chapter provides a description of the parameters for each point as well as examples of the connections to other points.

Tank Gate Interface software blocks are functions that the user can configure to perform various tasks. Software Blocks are available to scan data from a slave device, control a pump, serve data to other Host systems or perform calculations. Each function type contains both the code and data necessary to perform the function. Software Blocks are identified by their type (example: AI, DI, LJ2000 and PUMP). Points are individual instances of software blocks. Each point must be added and then configured. Adding a point makes the point available for configuration. All defined points appear in both the Point Icon Selection area and the Spreadsheet Summary in the main window.

Configuring the point involves entering configuration parameters. In some cases, connections to other points are required in order to perform a task. Creating connections involves setting references to allow data to be transferred between points.

7.6.1 Overview

An outline of the section is listed below:

Configuring Single Points

This section describes the method used to configure individual points including:

- Adding a Point
- This section describes how to define a point from the Main window.
- Entering Point Data
- This section describes how to enter the point's parameters. Parameters are entered from the Edit Point Window.
- Modifying Strap Tables
- This section describes how to modify strap tables in ViewRTU.

Configuring Multiple Points

This section describes the spreadsheet mode. The principles involved in point configuration are the same, but the methods are slightly different.

- Adding Multiple Points
- This section describes how to define a point from either the Main window or the Spreadsheet Mode window.
- Entering Point Data
- This section describes how to enter a point's parameters. Parameters are entered from the Spreadsheet Mode window.

Creating and Editing Connections

This section describes how to create connections between various points. Points may be used to retrieve and/or deliver data from other points.

7.6.2 Configuring Single Points

Configuring the point involves entering configuration parameters. In some cases, connections between points must also be required in order to perform a function. All of these steps can be implemented from the Point Connections window. To display the Point Connections window, follow one of the methods listed below:

Adding a Point



The user is able to add a point or point type by clicking on the Add Point push-button from the toolbar or by selecting Add from the Point menu. Once the point is added, the user is then able to configure the point. Defined point types appear in the Point Icon Selection Area and in the Spreadsheet Summary of the main window.

Entering Point Data

This section describes how to configure the parameters of any point. Each point has its own Edit Point window that requires some degree of configuration. Both the configuration and dynamic attributes of the point are found in the Edit Point Window. From this window, the user is able to view and edit database parameters.

Several methods can be used to display this window depending on the user's current location in the program:

- If in the Main window, select Edit from the Point menu. Select the desired point type and corresponding point number.
- If in the main window, double-right click on the point icon.
- If in the Point Connections window, double-left click on the focus point icon.
- If in the Point Connections window, double-right click on a point icon other than the focus point icon.

The following example window appears.

EDIT POINT

Point Help

Current Point # Point Desc: DI.00 : Digital Inputs

CONFIG

Tag	Point Tag	VCP1.H0A Auto
Description	Point Description	VCP1 Hand/Off/Auto Switch
Channel	Input Channel	1
ChanQuan	Channel Quantity	1
Value_0	Value for RawValue=0	Off
Value_1	Value for RawValue=1	On
Value_2	Value for RawValue=2	Undefined
Value_3	Value for RawValue=3	Undefined
Reverse	Reverse	No
Latch	Latch	No

DYNAMIC/COMMAND

Value	Digital Input Value	Undefined
RawValue	Raw Input Value	0x0000
PntStatus	Point Status	0
Elapse	Time of Last Update	Sun Jan 04 16:03:02 2004
PntChecksum	Point CheckSum	0x0000

Minimize Next Examine Download
Connections Previous Exit Upload

Figure 7-22:Edit (Digital) Point dialog

Edit (Digital) Point dialog

This window is used to view and modify the Dynamic and Configuration parameters of the selected point. The Edit Point window is identified by the Point Description and associated current Point Number listed at the top of the window.

This window contains two list boxes and a series of push-buttons. The top list box contains the configuration parameters of the point, while the bottom list box contains Dynamic and Command parameters.

The first column contains the name of the parameter and the second column contains descriptions of the parameters. The third column of the Configuration parameters section contains the default data. The user can change a value by double-clicking an entry and entering the new variable. If a Tank Gate Interface is connected and on-line, the third column of the Dynamic parameters will update in real-time.

Edit Point Window Push-buttons

The user is able to perform a series of functions from selecting the push-buttons found in the bottom of the Edit Point window. Each push-button is described below.

Minimize

The Minimize push-button creates a “mini window” of selected parameters. This push-button enables the user to observe relationships between dynamic parameters and how the changes affect the point.

Clicking the Minimize shrinks the window so that only one or more selected list box parameters are displayed. The user may have multiple minimize windows opened simultaneously. This capability is useful for testing and debugging.

Minimizing the Edit Point Window

- Highlight by single-clicking the left mouse button on one or more parameters.
- Click on the Minimize push-button. A following example window appears:



Figure 7-23:Edit Point dialog minimized

Note Parameters can be edited in the minimized mode by double-clicking the right mouse button on the desired selection.

- To maximize the window, click on the maximize icon or click on the Application Control menu of the window and select the Maximize menu option.

Connections

The Connections push-button allows the user to switch back to the Point Connections dialog box.

Next

The Next push-button allows the user to step through the list of points. The user is able to view the Edit Point window of the following point number. Selecting Next at the end of the point number list wraps to the beginning.

Previous

The Previous push-button allows the user to step through multiple points of a point type. The user is able to view the data in the Edit Point window of the previous point. Selecting Previous at the first point number wraps to the last point number of the list.

Examine

The Examine push-button is used to go to the Point Connections window of the reference point in the list box.

Opening a point connection window

- Highlight the desired reference data parameter from the Edit Point window.
- Click on the Examine push-button.

The user is taken to that reference point's Point Connections window.

Exit

The Exit push-button exits the current point configuration and returns the user to the main menu.

Download

The Download push-button allows the user to download the entire point data to the Tank Gate Interface.

Upload

The Upload push-button allows the user to upload the entire point data from the Tank Gate Interface.

7.6.3 To modify a Value

EDIT POINT

Point Help

Current Point # Point Desc: VALVE.00 : Valve Status/Control

CONFIG

Tag	Point Tag	VALVE.00
Description	Point Description	VALVE.00
OpenedRef	Opened Limit Switch Reference	Undefined
ClosedRef	Closed Limit Switch Reference	Undefined
HOARef	Hand/Off/Auto Reference	Undefined
PositionRef	Valve Position Reference	Undefined
Mode	Operating Mode	Hold
DataMode	OpCondition Offset	0
CoastDown	Reverse Command Coastdown	00:00:10
TransTimeOut	Transition Time Max	00:02:00

DYNAMIC/COMMAND

Command	Open/Close/Stop/Reverse	Undefined
Setpoint	Position Setpoint	0.0
LastCommand	Last Operator Command	Undefined
CommandTime	Last Command Time	Tue Jan 01 00:00:00 1980
Value	Valve Status	Undefined
OpCondition	Operating Condition	0
HOAValue	Hand/Off/Auto Status	Undefined
ValvePosition	Valve Position	0.0
PntStatus	Point Status	0
Elapse	Time of Last Update	Tue Jan 01 00:00:00 1980

Buttons: Minimize, Next, Examine, Download, Connections, Previous, Exit, Upload

Figure 7-24: Edit Point dialog (adding a value)

To modify a value

- Double-click the desired parameter to enter a new value. The following example Modify Point dialog box appears.




Figure 7-25: Edit point parameter value dialog

Edit point parameter value dialog

From this dialog box, the user is able to enter a value for the selected parameter. The dialog box varies according to the selected parameter. In some dialog boxes the user is able to enter the name or data directly in the edit box. Other dialogs contain a scroll list from which the user selects a value. The new value can then be downloaded to the Tank Gate Interface or stored locally if the Tank Gate Interface is off-line.

To modify a Reference

There are two ways to modify a reference. One method is performed from the Edit Point window, and the other method is performed from the Point Connections window. For convenience, both methods are listed below:

To modify a Reference

- In the Edit Point Window Double-click the desired reference parameter to enter a new value. The following dialog box appears.
- In the Point Connections Window drag and drop the point icon onto the PntRef. The following dialog box appears.




Figure 7-26: Edit point parameter reference dialog

Edit point parameter reference dialog

This dialog box is used to select a new point reference, corresponding point reference number, and/or parameter. If displayed from the Edit Point window, the selection lists the default value. If displayed from the Point Connections window, the most consistent value is selected as the default.

Only valid references appear in the list boxes contained in this dialog box. The new reference can then be downloaded to the Tank Gate Interface or stored locally if the Tank Gate Interface is off-line.

7.6.4 Configuring Multiple Points

The spreadsheet mode is one of the methods used to configure points. This method is the most beneficial when editing and viewing multiple points of the same type. Spreadsheets of each defined point are found in the Spreadsheet Summary section in the main window.

There are some differences between the regular and spreadsheet methods. First, the user is not able to view the Point Connections window in Spreadsheet Mode. This mode is used mainly for viewing and entering point data. Second, the spreadsheet focuses on points of a single type; it does not offer a “big picture” view of multiple point types.

Adding Multiple Points



The user is able to add a point by using the same method used to add single points. The user can click on the Add Point icon or push-button from the toolbar or by selecting Add from the Point menu in the Main window. Once the point is added, the user is then able to define the point. Defined points appear in the Point Icon Selection Area and in the Spreadsheet Summary of the Main window.

Note The user can add a point by selecting Add from the Point menu in the Spreadsheet Mode window. This menu is described later in the section.

Adding Multiple Points

- Double-click on the desired point type in the Spreadsheet Summary. The following example Spreadsheet Mode window appears.


SPREADSHEET MODE							
Point Edit Options							
D	U		Tag	Mode	LevelRef	TempRef	WaterRef
D	U	0	TANK.00	0	NMS53.00.Level	AI.00.Value	AI.01.Value
D	U	1	TANK.01	0	NMS53.01.Level	AI.02.Value	AI.09.Value
D	U	2	TANK.02	0	NMS53.02.Level	AI.03.Value	AI.10.Value
D	U	3	TANK.03	0	NMS53.03.Level	AI.04.Value	AI.11.Value
D	U	4	TANK.04	0	NMS53.04.Level	AI.05.Value	AI.12.Value
D	U	5	TANK.05	0	NMS53.05.Level	AI.06.Value	AI.13.Value
D	U	6	TANK.06	0	NMS53.06.Level	AI.07.Value	AI.14.Value
D	U	7	TANK.07	0	NMS53.07.Level	AI.08.Value	AI.15.Value

Figure 7-27: Spreadsheet Mode Window

Note Refer to the following Entering Point Data section for a description of the Spreadsheet Mode window.

Entering Point Data

This section explains the window used to configure multiple points of a single point type. When the user double-clicks on a point type, the following example dialog box appears:



The screenshot shows a window titled "SPREADSHEET MODE" with a menu bar containing "Point", "Edit", and "Options". Below the menu bar is a table with the following columns: "D", "U", "Tag", "Mode", "LevelRef", "TempRef", and "WaterRef". The table contains eight rows of data, each representing a point. The "D" and "U" columns are for download and upload actions, respectively. The "Tag" column lists the point names (TANK.00 to TANK.07). The "Mode" column shows the mode (0). The "LevelRef", "TempRef", and "WaterRef" columns show the corresponding parameter values.

D	U	Tag	Mode	LevelRef	TempRef	WaterRef
		0	TANK.00	0	NMS53.00.Level	AI.00.Value
		1	TANK.01	0	NMS53.01.Level	AI.02.Value
		2	TANK.02	0	NMS53.02.Level	AI.03.Value
		3	TANK.03	0	NMS53.03.Level	AI.04.Value
		4	TANK.04	0	NMS53.04.Level	AI.05.Value
		5	TANK.05	0	NMS53.05.Level	AI.06.Value
		6	TANK.06	0	NMS53.06.Level	AI.07.Value
		7	TANK.07	0	NMS53.07.Level	AI.08.Value

Figure 7-28: Spreadsheet Mode: Entering point parameter data

Spreadsheet Mode


This window displays a list of all the point numbers of a selected point type. The user is able to add, configure, and edit points. The user is able to select and enter the parameters for each point or group of points. The user can also export/import files and control the selection of displayed parameters.

Compare this window to the Edit Point window (see Figure 7-7 on page 78). The two windows contain the same parameters. In the spreadsheet mode, the user is able to view and modify all the points of the selected type. In the Edit Point window, the user steps through a window for each point number using the Next and Previous push-buttons.

The left two columns, D and U are used to download and upload, respectively, the information found in the corresponding row(s). The third column lists the point numbers. The Spreadsheet Mode menu bar contains menus used to perform various functions to one or more points. Each of the Spreadsheet Mode menus is described below.

The Point Menu

This menu contains the same menu options found in the main window's menu bar. Refer to The Point Menu section for a description of the menu options.



The screenshot shows the same "SPREADSHEET MODE" window as Figure 7-28, but with the "Point" menu open. The menu options are: "Add..." (Ctrl+A), "Edit..." (Ctrl+E), "Delete..." (Ctrl+Y), and "Select...". The table below the menu bar is the same as in Figure 7-28.

D	U	Tag	Mode	LevelRef	TempRef	WaterRef
		0	TANK.00	0	NMS53.00.Level	AI.00.Value
		1	TANK.01	0	NMS53.01.Level	AI.02.Value
		2	TANK.02	0	NMS53.02.Level	AI.03.Value
		3	TANK.03	0	NMS53.03.Level	AI.04.Value
		4	TANK.04	0	NMS53.04.Level	AI.05.Value
		5	TANK.05	0	NMS53.05.Level	AI.06.Value
		6	TANK.06	0	NMS53.06.Level	AI.07.Value
		7	TANK.07	0	NMS53.07.Level	AI.08.Value

Figure 7-29: Spreadsheet Mode: The Point Menu

This option is useful for creating, deleting and editing points without having to exit out of the Spreadsheet mode.

The Edit Menu




Figure 7-30: Spreadsheet Mode: The Edit Menu

Copy

The Copy option allows the user to copy data from a one or more selected cells.

1. Select one or more cells to copy. To select one or more rows, click on the number(s). To select one or more columns, click on the parameter(s).
2. Select the Copy option from the Edit menu. The selected cells outline changes from black to red.

Note To undo the Copy option, press the Esc key. Pressing the Esc key removes the selection outline from the selected cells.

Paste

The Paste option allows the user to paste the copied group of cells (red outline) to the currently selected group of cells (black outline).

1. Select the cells on which the copied cells will be pasted.
2. Select the Paste option from the Edit menu.

1. Click on each desired cell or column.
2. Select Set Value from the Edit menu. The following dialog box appears:




Figure 7-33: Spreadsheet Mode: Editing point parameter values using auto increment

Each value in the column is incremented by one for the range of rows selected. All cells that are selected and match the data type of the value are set to the value.

The Options Menu




Figure 7-34: Spreadsheet Mode: The Options Menu

Import

The Import option allows the user to import a point or group of points that match the current point type. The imported file is named according to the point type with the 'CSV' file extension.

Export

The Export option allows the user to export a selected point or all the points that match the current point type to the default directory. The export file is saved in a file named according to the point type with the 'CSV' file extension.

Note The user is able to change the source directory in the INI file.

View

The View option allows the user to display selected parameter types. Selecting this option displays the following View Point Parameters dialog box.




Figure 7-35: Spreadsheet Mode: Viewing selected parameter types dialog

The user is able to select any combination of parameter types. The user is able to select any combination of classifications. The classifications are described briefly below.

Parameter Type	Description
Dynamic	Real-time data such as status
Config	General specifications such as tag and description
Constant	Data that does not change and/or can not be changed
Scratch	Temporary data that is typically hidden from the user
Command	Output command data
System	System data (should not be changed by the user)

Note The default View setting is the Config parameter type.

Hide Row/Col

The Hide Row/Col option allows the user to hide selected rows or columns.

Note The Copy and Paste operations do not affect hidden rows and columns.

1. Select one or more rows or columns.
2. Select the Hide Row/Col option from the Options menu.

The selected rows or columns are indicated by a '+' in the row or column buttons heading. The following dialog box illustrates this feature.




Figure 7-36: Spreadsheet Mode: Hiding columns

The user can unhide a row or column by clicking on the associated '+'. To unhide all the rows / columns, the user can select the Unhide All option from the Options menu.

Unhide All

The Unhide All option allows the user to reveal all of the rows or columns that are currently hidden.

7.6.5 Creating and Editing Connections

Several methods can be used to display this window depending on the user's current location in the program. These methods are listed below:

- If in the Main window, double-left click on the point icon.
- If in the Edit Point window, click on the Connections push-button.
- If in the Point Connections window, double-left click on a point icon other than the focus point to view the Point Connections window for the selected point.

Note If multiple points exist, a selection window is displayed showing all the available points.




Figure 7-37: Edit Point selection window

Displaying the Point Connections window.

- Double-click on one of the icons to display the Point Connections window. The following example Point Connections window appears.




Figure 7-38: Point Connections Window

Point Connections Window

This graphic display visually illustrates the reference connections of the focus point. From this display, the user is able to select reference points, create connections between these points, and enter configuration parameters.

The point icons located in the Icon Bar utilize the drag-and-drop features of Windows. The user is able to connect the output data of one point to the input of another point.

The connections are made through point references and links. Not all points have references, but any parameter of a point can be referenced. Some references are incompatible with some types of data. The program can determine if a reference is valid, but it cannot determine if the reference is meaningful.

The Input Data parameters, which are located on the left side of the software block, are references. The Output Data parameters, which are located on the right side, are most commonly referenced by other points.

To create a Connection:

- Select the desired point icon from the Icon Bar and drag it onto the desired data parameter.
 - If the point dropped does not exist, then the user needs to define the point as described in the previous section. The same configuration process is used to define the point.
 - If multiple points exist, the user is prompted to select the point number.
 - If the point dropped already contains a reference to another input reference, a dialog box will appear inquiring whether or not to overwrite the existing reference.
- The point icon will appear to the right or left of the selected arrow as seen Figure 7-38.

Note Double-left clicking on a focus point icon allows the user to view the point's Edit Point window.

Note Double-left clicking on the input source or the output destination icon allows the user to step through each corresponding Point Connections window, if applicable.

Note Double-right clicking on the input source or the output destination icon allows the user to view the point's Edit Point window.

8 Troubleshooting

8.1 Overview

This chapter describes the procedures used to isolate hardware faults. Three push-buttons and eight status Led provide verification of Tank Gate Interface proper operation. If the Tank Gate Interface is not functioning normally, the user is able to troubleshoot the device by performing one or more procedures using the three push-buttons. These push-buttons and indicators are also described in the Motherboard & I/O ExpansSAAB TRL/2ion Module Configuration chapter.

Caution! Not all troubleshooting instructions are valid for all Communications Modules.


8.2 Troubleshooting the Tank Gate Interface

8.2.1 LED Displays under normal conditions

Operations are normal if the Run, I/O and On-line indicators are flashing. the table below represents the normal conditions for the Run, Output and On-line indicators.

Figure 8-1: LED Indicators

Indicator	Condition
Run	Flashes once every second.
Com	Toggles when the system is receiving data. Idle when not receiving data.
TXD	Every P011 causes the TXD LED to toggle
RXD	Lights when a response is received



Run indicator

The RUN Indicator provides the single most important feedback of proper system operation. When the system functions properly, the RUN Indicator is constantly flashing at a 0.5Hz rate. If this indicator ever goes to a steady state condition, either on or off, some malfunction has occurred. In addition, relative processor loading can be determined by observing the RUN Indicator duty cycle. Under normal conditions, this indicator flashes once every second.

Communications indicator

The Communications indicator provides communication line status. When it is toggling, the system is exchanging data. As the system receives a valid message from the Host, this indicator toggles. If the indicator is idle, the system is off-line.

TXD/RXD LEDs

When these LEDs are flashing, the system is exchanging data between the Tank Gate Interface and any tank gauge.

8.2.2 LED Displays under Abnormal Conditions

The table below lists the abnormal conditions of the four indicator lights. From this table the user should be able to pinpoint the cause and derive a solution to the problem.

Indicator	Condition	Cause	Solution
Run	Does not flash (even after hard reset)	Bad database Bad main circuit board	Perform Hard Reset then reload database Replace main circuit board
	Steady ON/OFF	system failure	
Communication	Steady state	DIP switch setting	Check unit ID DIP switch setting: set ID number and reset system
		COM point	Check COM point with diagnostics terminal or ViewRTU
		COM parameters	Verify time-out, baud, and protocol parameters have the correct values set
		bad communications	Check for bad communication line, modem board or main circuit board
		wrong jumper settings	Check SW1 & SW2 for proper settings

8.2.3 Using the Tank Gate Interface Push-buttons

Reinitializing System Hardware

To reinitialize the system hardware

- Press the RESET Switch.

This action causes it to go to a known starting state. This switch may be pressed at any time; however, the following will also occur:

- Reinitialize System Hardware
- Clear Working Memory
- Reinitialize Data Base
- Reset All Timers
- Disable Outputs
- Enable Communications
- Present Sign-on Message to Diagnostic Terminal

8.2.4 Performing a Hard Reset

A 'Hard Reset' clears the Tank Gate Interface's database. The following procedure describes the steps necessary to perform a Hard Reset:

1. Set the ID DIP switch to 15 (all switches Closed/On). This action initiates the Hard Reset Procedure.




Figure 8-1: Set the ID DIP switch to 15

2. Press the Reset button




Figure 8-2: Switches SW3 on the Tank Gate Interface motherboard

3. The Tank Gate Interface will perform its memory test. When it has completed the memory test, all LEDs will be on.
4. Set the ID DIP Switch to the desired address (1–14). At this point, there is no further action required by the user.




Figure 8-3: Set the ID DIP switch to the desired addresses

5. The LEDs will light (and remain steady) to indicate the address. For example, if the ID DIP Switch is set to 1, LED D1 will be on. If the ID DIP Switch is set to 3, LEDs D1 and D2 will be on.




Figure 8-4: Address indication from the LEDs

6. After 10 seconds, the address of the Tank Gate Interface will be set to the ID DIP Switch setting. The LEDs will flash for 5 seconds to indicate that the address is about to be set.




Figure 8-5: Set the ID addresses

7. After the address is set, the Tank Gate Interface will begin normal operation with a blank database:
 - CPU LED: Flashing once per second
 - COM LED: Toggles when communicating to PC
 - TXD: Off when there is no database. When tank gauges are being scanned, the TXD LED will flash
 - RXD: Off when there is no database. When tank gauges are being scanned, the RXD LED will flash when a response is received.

8.3 Maintenance

Field maintenance of the Tank Gate Interface is simplified by several built-in features. The modular design of the computer control system, in conjunction with quick-disconnect connectors, allows for on-site replacement of questionable components.

The following standard procedure can be used for repairing the Tank Gate Interface:

Replacing a defective component or module

- Turn off main power.
- Open the enclosure door. Remove the case cover of the Tank Gate Interface.
- Replace the defective component or module using the instruction supplied with the spare part.

- Replace and tighten the case cover.
- Turn on power and test with PC and ViewRTU.
- Close the enclosure door.

A Appendix - Order Codes

10	Interface Module		
	032	Dual RS-485 MODBUS™ Communications Interface Module	
	036	Dual RS-485 GSI ASCII Communications Interface Module	
	101	Varec Mark/Space Micro 4-wire (Varec 1800, 1900, 6500) Interface Module	
	111	Current Loop (Whessoe Bus) Interface Module	
	112	Current Loop (GPE) Interface Module	
	120	SAAB (TRL/2) Interface Module	
	140	Enraf (811, 802/812, 854, 873) Interface Module	
	150	L&J Tankway (MCG 1000, MCG 1500, MCG 2000) Interface Module	
	161	Prime Measurement (3500 ATG) Interface Module	
	171	Dual RS-232 Veeder Root (TLS 350) Interface Module	
20	Enclosure		
	A	No Enclosure (Note 1)	
	B	16x16x6 inch NEMA 4 enclosure	
30	Power Supply		
	0	No DC Power Supply (Note 1, 2)	
	1	120VAC input, 48VDC, 1 Amp Power Supply (Note 3)	
	2	240VAC input, 48VDC, 1 Amp Power Supply (Note 3)	
	3	120VAC input, 24VDC, 1 Amp Power Supply (Note 3, 4)	
	4	240VAC input, 24VDC , 1 Amp Power Supply (Note 3, 4)	
N83-			Complete product designation

Note 1: If 'No Enclosure' is selected, then 'No DC Power Supply' must be selected.

Note 2: Not available for Mark/Space or Current Loop Interface Modules unless 'No Enclosure' option selected

Note 3: Not available for SAAB, Enraf, L&J Tankway, Prime Measurement, or Veeder Root (TLS 350) Interface Modules

Note 4: Only available with Dual RS 485 Interface Modules with enclosure

