

2500 Automatic Tank Gauge—Cast Iron

Spare Parts



Name

Company

Tel:

Fax:

E-mail:

Date:

Date Parts Required:

Delivery Address:

Billing Address:

End User Information:

(Name, Company, City, State, Zip)

Purchase Order Number:

Shipping Instructions:

Special Instructions:

Ordering Instructions:

When ordering spare parts refer to the diagram for item numbers. Complete this form in full and then fax-back to (770) 810-9456, or contact your Varec local representative.

Item	Part No.	Description
01	B4396-046	Back Cover Gasket (Type A Gaugeheads prior to 1983, and Low Pressure Iron Gaugeheads)
02	B5059-046	Back Cover Cap Gasket (For a transmitter)
	B5059-146	Back Cover Cap Gasket - No center hole (if no transmitter)
03ci	B5060-001-7	Back Cover Cap, Painted (Cast Iron Gaugehead)
04	B7415-093	Teflon Washer (Not shown - used on older Gaugeheads)
05	B8235-040	English Dial Gear
	B8327-040	Metric Dial Gear
06	02-013187-046	Counter Cover Gasket
07	B8218-001	English Dial Plate (Fractional or Decimal)
	B8325-001	Metric Dial Plate (30 cm Graduations) Innage/Outage
08ci	BB7761	Tape Storage Sheave Assembly (Includes item 58) (Cast Iron Gaugehead)
09	B8234-001	Dial Retainer
10	BA7763	Shaft Support Assy (2) (Type C & Cast Iron Gaugeheads)
11	BA17597	Counter Shaft/Hub Assembly
13	P34-4	Knob, Phenolic, Black
14	BA14055	Gauge Check Assembly (includes items 61 & 62)
15	B7796-005	Gauge Check Spring - 304 SS
16	B6547-005	Tape Keeper Post
17	D1895-002	Back Cover - Cast Iron (16 bolt holes)
18	DB3197	Cast Iron Sprocket Sheave Assy - English (Cast Iron Gaugeheads) (Includes 2 # 28)
	DB3930	Cast Iron Sprocket Sheave Assy - Metric (Cast Iron Gaugeheads) (Includes 2 # 28)
19	DA4044-7	Counter Cover Assembly - Painted (includes items 53 & 54)
21	BM18849-100	English Counter Assembly
	BM18850-100	Metric Counter Assembly
22	P14-146	O-Ring Seal-Viton
23	P10-2	Retaining Ring, ((2) std motors, (1) cassettes)
24	P25-16	Pinion Gear
25	B7300-005	Tape Keeper Spring
26	P14-23	O Ring Seal, Teflon
27	P31-669	Screw (for tape keeper)
28	P31-1467	(2) Set Screw (for Counter Sprocket)
29	P10-29	Grip Ring 3/8"
33	02-08543	Washer, shim
34	P030-04-822	1-1/2 NPT Plug
35	P30-237	1/2 NPT Top Plug (Type B Gaugeheads & iron)
36	P031-32-1661	Washer, Fiber
37	B4847-005	Washer, (Inside at counter)
38	P031-05-1721	Back Cover Bolts
39	P031-05-1871	Hex Head Cap Screw (Counter cover)
40	P031-01-1719	Binding Head Mach. Screw (Brass for counter)
41	P31-247	Hex Jam Nut (For back cap)
42	P31-612	Set Screw, (For check knob)
43	P031-08-1720	Screw (For counter base)
44	P31-1	Washer
45	P31-13	Shim washer
47	P031-05-1601	Hex Head Cap Screw (For back cap)
48	BC7762	Negator Motor Sheave Assembly (Cast Iron Gaugeheads, includes items 55x2 & 56)
52	BM3784	Handle (Crank) (for Cast Iron Gauge)
53	P30-236	Top Counter 1/4 NPT Plug
54	B12759-003	Bottom Counter 1/4 NPT Drain Plug

For more information visit www.tankgauging.com

Item	Part No.	Description
55	02-09598	Bushing, shoulder (PTFE)
56	B14872-105	Motor Top Plate, For Iron Gauge
57	P31-671	Screw (Motor, output)
61	B7790-005	Check Pawl
62	B7795-005	Hair Pin Spring
96	P10-54	Retaining Ring for Counter Gland (Cast Iron Gaugeheads)
97	B14057-001-7	Gauge Check Seal Plate (Cast Iron Gaugeheads)
98	P31-1113	Seal Plate Screws (Cast Iron Gaugeheads)
99	BE18440	Counter Gland Assy (Cast Iron Gaugeheads)

APM037GVAEAPM037GVAE

